

# HP StorageWorks

## Edge Switch 2/32 installation guide

FW 07.00.00/HAFM SW 08.06.00

Part number: AA-RSTZE-TE/958-000290-003  
Fifth edition: March 2005



**Legal and notice information**

© Copyright 2001–2005 Hewlett-Packard Development Company, L.P.

© Copyright 2003–2005 McDATA Corporation.

Hewlett-Packard Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Hewlett-Packard. The information is provided "as is" without warranty of any kind and is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Intel is a trademark or registered trademark of Intel Corporation or its subsidiaries in the United States and other countries.

Java is a US trademark of Sun Microsystems, Inc.

Microsoft, Windows, and Windows NT are U.S. registered trademarks of Microsoft Corporation.

Linux is a U.S. registered trademark of Linus Torvalds.

UNIX is a registered trademark of The Open Group.

Printed in the US

Edge Switch 2/32 installation guide

---

# Contents

About this guide . . . . .	9
Intended audience . . . . .	9
Related documentation . . . . .	9
Document conventions and symbols . . . . .	10
Rack stability . . . . .	11
HP technical support . . . . .	11
HP-authorized reseller . . . . .	11
Helpful web sites . . . . .	12
1 Introduction . . . . .	13
Switch description . . . . .	13
Features . . . . .	13
Switch management. . . . .	14
Error-Detection, reporting, and serviceability . . . . .	14
Zoning . . . . .	16
Multiswitch fabrics . . . . .	16
Hardware components . . . . .	16
Front view. . . . .	17
Rear view . . . . .	17
SFP transceivers (fiber optic connectors) . . . . .	18
Cooling fans . . . . .	18
Power supplies . . . . .	18
Connectors and indicators . . . . .	18
Initial machine load button. . . . .	18
Ethernet LAN connector . . . . .	19
Power and system error LEDs . . . . .	19
FRU status LEDs. . . . .	19
Maintenance port . . . . .	19
Tools and test equipment . . . . .	20
Tools supplied with the switch . . . . .	20
Tools supplied by service personnel . . . . .	21
Optional kits . . . . .	22
2 Installing and configuring the Edge Switch 2/32. . . . .	23
Installation options . . . . .	23
Review installation requirements . . . . .	23
Unpack and inspect the switch . . . . .	24
Install the Edge Switch on a desktop . . . . .	25

Install the Edge Switch in a Rack . . . . .	26
Rack mount checklist . . . . .	26
Mounting hardware . . . . .	26
Brackets and rails . . . . .	26
Required tools . . . . .	27
Mounting the adjustable brackets in the rack. . . . .	27
Mounting the slide rails on the sides of the switch . . . . .	28
Installing the switch in the cabinet . . . . .	29
Configure switch network information . . . . .	30
Changing the switch address . . . . .	31
LAN-connect the switch . . . . .	34
HAFM appliance . . . . .	34
Record or verify HAFM appliance restore information . . . . .	35
Enabling HAFM to manage the switch . . . . .	35
Verify Communication between the switch and the HAFM appliance . . . . .	36
Set Switch date and time . . . . .	38
Set date and time manually. . . . .	38
Periodically synchronize date and time. . . . .	38
Frequently used HAFM settings. . . . .	39
Set the switch online . . . . .	39
Set the switch offline . . . . .	40
Configure switch identification . . . . .	40
Configure switch management style . . . . .	41
Configure Switch Operating Parameters . . . . .	42
Switch parameters . . . . .	42
Domain ID . . . . .	42
Preferred. . . . .	43
Insistent . . . . .	43
Rerouting Delay . . . . .	43
Domain RSCNs . . . . .	44
Suppress RSCNs on zone set activations. . . . .	44
Configure fabric operating parameters. . . . .	44
Fabric parameters. . . . .	45
BB_Credit . . . . .	45
R_A_TOV . . . . .	45
E_D_TOV . . . . .	46
Switch priority . . . . .	46
Interop Mode . . . . .	47
Configure switch binding . . . . .	47
Configure ports (Open Systems management style) . . . . .	47
Configure preferred ports . . . . .	50
Configure ports (FICON management style) . . . . .	51
Configure port addresses (FICON). . . . .	52
Configure SNMP trap message recipients. . . . .	53
Configure, enable, and test e-mail notification. . . . .	54
Configure and enable call-home features . . . . .	56
Configure and enable ethernet events . . . . .	56

Configure, enable, and test call home event notification . . . . .	57
Configure threshold alerts . . . . .	57
Create new alerts . . . . .	58
Modify alerts . . . . .	62
Activate or deactivate alerts . . . . .	62
Delete alerts . . . . .	62
Configure SANtegrity authentication . . . . .	63
Back up HAFM configuration data . . . . .	64
Configure Open Systems management appliance . . . . .	64
Configure FICON management appliance . . . . .	64
Configure feature key . . . . .	64
Configure Open Trunking . . . . .	64
Enable Embedded Web Server . . . . .	64
Enable Telnet . . . . .	64
Connect cables to Fibre Channel ports . . . . .	65
Connect the switch to a Fabric . . . . .	65
Unpack, inspect, and install the Ethernet hub (optional) . . . . .	67
Using HAFM from a remote location . . . . .	67
Remote workstation minimum requirements . . . . .	67
Install HAFM client on a remote workstation . . . . .	68
Launch HAFM from the remote client . . . . .	69
<b>3 Using the Embedded Web Server . . . . .</b>	<b>71</b>
Launch EWS . . . . .	71
Configure switch ports . . . . .	73
Configure switch identification . . . . .	74
Configure date and time . . . . .	75
Configure switch and fabric parameters . . . . .	76
Configure switch parameters . . . . .	76
Set fabric parameters . . . . .	77
Configure network information . . . . .	79
Configure SNMP trap message recipients . . . . .	80
Enable or disable the CLI . . . . .	82
Configure user rights . . . . .	82
Reset configuration data . . . . .	83
<b>4 Manage firmware versions . . . . .</b>	<b>87</b>
Determine a switch firmware version . . . . .	87
Add a firmware version . . . . .	88
Modify a Firmware version description . . . . .	90
Delete a firmware version . . . . .	90
Download a firmware version to a switch . . . . .	91
Back up the configuration . . . . .	92
Restore the Configuration . . . . .	93

<b>A Regulatory compliance and safety</b>	<b>95</b>
Regulatory compliance	95
Federal Communications Commission notice	95
Class A equipment	95
Class B equipment	96
Declaration of conformity for products marked with the FCC logo, United States only	96
Modifications	96
Cables	96
Regulatory compliance identification numbers	97
Laser device	97
Laser safety warning	97
Certification and classification information	97
Laser product label	97
International notices and statements	98
Canadian notice (avis Canadien)	98
Class A equipment	98
Class B equipment	98
European Union notice	98
BSMI notice	98
Japanese notice	99
Korean notices	99
Safety	99
Battery replacement notice	99
Taiwan battery recycling notice	100
Power cords	100
Japanese power cord notice	101
Electrostatic discharge	101
Preventing electrostatic damage	101
Grounding methods	101
<b>B Technical specifications</b>	<b>103</b>
Factory defaults	103
Physical dimensions	105
Environmental specifications	105
Power requirements	106
Operating tolerances	106
Laser information	107
<b>Index</b>	<b>109</b>
<b>Figures</b>	
1 Edge Switch 2/32 (front view)	17
2 Edge Switch 2/32 (rear view)	17
3 Loopback plug	20
4 Fiber-Optic protective plug	20
5 Null modem cable	21
6 Brackets included in kit	27

7	Attaching the slide rail to the switch . . . . .	29
8	Connection Description dialog box . . . . .	31
9	Connect To dialog box. . . . .	32
10	Port Settings dialog box . . . . .	32
11	HyperTerminal window . . . . .	33
12	Disconnect Now dialog box . . . . .	33
13	Save Session dialog box . . . . .	34
14	Discover Setup dialog box . . . . .	35
15	Domain Information dialog box (IP Address page) . . . . .	35
16	Switch Hardware View page . . . . .	37
17	Configure Date and Time dialog box . . . . .	38
18	Configure Identification dialog box . . . . .	40
19	Configure Switch Parameters dialog box . . . . .	42
20	Configure Fabric Parameters dialog box. . . . .	45
21	Configure Ports dialog box (Open Systems management style) . . . . .	48
22	Configure Preferred Paths dialog box. . . . .	50
23	Add Preferred Path dialog box . . . . .	50
24	Configure Ports dialog box (FICON management style) . . . . .	51
25	Configure SNMP Agent dialog box . . . . .	53
26	Configure Email dialog box . . . . .	54
27	HA FM 8.6 Server Users dialog box . . . . .	55
28	Define Filter dialog box . . . . .	55
29	Configure Ethernet Events dialog box. . . . .	56
30	Call Home Event Notification Setup dialog box. . . . .	57
31	Configure Threshold Alerts dialog box . . . . .	58
32	New Threshold Alerts dialog box—first screen . . . . .	59
33	New Threshold Alerts dialog box—second screen . . . . .	59
34	New Threshold Alerts dialog box—third screen. . . . .	60
35	New Threshold Alerts dialog box—summary screen. . . . .	61
36	Configure Threshold Alerts dialog box—alert activated . . . . .	61
37	SANtegrity Authorization dialog box . . . . .	63
38	Port Properties dialog box. . . . .	66
39	HA FM remote client install . . . . .	68
40	Enter Network Password dialog box . . . . .	72
41	Embedded Web Server interface—View window . . . . .	72
42	Configure Ports tab . . . . .	73
43	Switch page—Identification tab. . . . .	74
44	Switch page—Date/Time tab . . . . .	75
45	Switch page—Parameters tab . . . . .	76
46	Switch page—Fabric Parameters tab . . . . .	78
47	Switch page—Network tab. . . . .	79
48	Network configuration changes activated . . . . .	80
49	Management page—SNMP tab . . . . .	81
50	Management page—CLI tab. . . . .	82
51	Auth Users tab. . . . .	83
52	Reset Configuration dialog box . . . . .	84
53	Discover Setup page . . . . .	85

54	Domain Information dialog box . . . . .	85
55	Firmware Library dialog box . . . . .	87
56	Firmware Library dialog box . . . . .	89
57	New Firmware Version dialog box . . . . .	89
58	New Firmware Description dialog box . . . . .	89
59	Modify Firmware Description dialog box . . . . .	90
60	Information dialog box . . . . .	93
61	Class 1 laser product label . . . . .	97

## Tables

1	Document conventions . . . . .	10
2	Edge Switch 2/32 optional kits . . . . .	22
3	Switch operational states and symbols . . . . .	36
4	Factory-set defaults . . . . .	103
5	Switch factory-default values for reset configuration option . . . . .	103
6	Dimensions . . . . .	105
7	Environmental specifications . . . . .	105
8	Power requirements . . . . .	106
9	Operating tolerances . . . . .	106
10	Laser specifications—2 Gb . . . . .	107



---

## About this guide

This guide provides information about:

- Installing the Edge Switch 2/32
- Performing initial configuration of the switch

## Intended audience

This guide is intended for:

- Fibre Channel technology
- HP StorageWorks Fibre Channel switches

## Related documentation

or a list of corresponding documentation included with this product, see the *Related documents* section of the *HP StorageWorks Edge Switch release notes*.

For the latest information, documentation, and firmware releases, please visit the HP StorageWorks website:

<http://h18006.www1.hp.com/storage/saninfrastructure.html>





For information about Fibre Channel standards, visit the Fibre Channel Industry Association website:

<http://www.fibrechannel.org>

# Document conventions and symbols

**Table 1** Document conventions

Convention	Element
Medium blue text: <a href="#">Figure 1</a>	Cross-reference links and e-mail addresses
Medium blue, underlined text ( <a href="http://www.hp.com">http://www.hp.com</a> )	Web site addresses
<b>Bold font</b>	<ul style="list-style-type: none"><li>• Key names</li><li>• Text typed into a GUI element, such as into a box</li><li>• GUI elements that are clicked or selected, such as menu and list items, buttons, and check boxes</li></ul>
<i>Italics font</i>	Text emphasis
Monospace font	<ul style="list-style-type: none"><li>• File and directory names</li><li>• System output</li><li>• Code</li><li>• Text typed at the command-line</li></ul>
<i>Monospace, italic font</i>	<ul style="list-style-type: none"><li>• Code variables</li><li>• Command-line variables</li></ul>
<b>Monospace, bold font</b>	Emphasis of file and directory names, system output, code, and text typed at the command line

-  **WARNING!** Indicates that failure to follow directions could result in bodily harm or death.
-  **CAUTION:** Indicates that failure to follow directions could result in damage to equipment or data.
-  **IMPORTANT:** Provides clarifying information or specific instructions.
-  **NOTE:** Provides additional information.


---

 **TIP:** Provides helpful hints and shortcuts.

---

## Rack stability

---

 **WARNING!** To reduce the risk of personal injury or damage to equipment:

- Extend leveling jacks to the floor.
  - Ensure that the full weight of the rack rests on the leveling jacks.
  - Install stabilizing feet on the rack.
  - In multiple-rack installations, secure racks together.
  - Extend only one rack component at a time. Racks may become unstable if more than one component is extended.
- 

## HP technical support

Telephone numbers for worldwide technical support are listed on the HP support web site:  
<http://www.hp.com/support/>.

Collect the following information before calling:

- Technical support registration number (if applicable)
- Product serial numbers
- Product model names and numbers
- Applicable error messages
- Operating system type and revision level
- Detailed, specific questions

For continuous quality improvement, calls may be recorded or monitored.

HP strongly recommends that customers sign up online using the Subscriber's choice web site at  
<http://www.hp.com/go/e-updates>.

- Subscribing to this service provides you with e-mail updates on the latest product enhancements, newest versions of drivers, and firmware documentation updates as well as instant access to numerous other product resources.
- After signing up, you can quickly locate your products by selecting **Business support** and then **Storage** under Product Category.

## HP-authorized reseller

For the name of your nearest HP-authorized reseller:

- In the United States, call 1-800-345-1518.
- Elsewhere, visit the HP web site: <http://www.hp.com>. Then click **Contact HP** to find locations and telephone numbers.

## Helpful web sites

For third-party product information, see the following HP web sites:

- <http://www.hp.com>
- <http://www.hp.com/go/storage>
- <http://www.hp.com/support/>
- <http://www.docs.hp.com>

---

# 1 Introduction

This chapter contains the following HP StorageWorks Edge Switch 2/32 information:

- [Switch description](#), page 13
- [Features](#), page 13
- [Hardware components](#), page 16
- [Tools and test equipment](#), page 20
- [Optional kits](#), page 22

## Switch description

The HP StorageWorks Edge Switch 2/32 provides dynamic switched connections between Fibre Channel servers and devices in a storage area network (SAN) environment. SANs introduce the concept of server-to-device networking and multiswitch fabrics, eliminate requirements for dedicated connections, and enable the enterprise to become data centric.

A SAN provides speed, high capacity, and flexibility for the enterprise, and is primarily based upon Fibre Channel architecture. The switch implements Fibre Channel technology that provides a bandwidth of 2.125 Gbps, redundant switched data paths, a scalable number of active ports, and long transmission distances (up to 35 km).

The switch can be installed on a table or desk top, or mounted in an equipment cabinet or in any standard equipment rack.

Multiple switches and the HAFM appliance communicate on a local area network (LAN) through one or more 10Base-T Ethernet hubs.

The switch provides dynamic switched connections for servers and devices, supports mainframe and open-systems interconnection (OSI) computing environments, and provides data transmission and flow control between device node ports (N\_Ports) as dictated by the Fibre Channel Physical and Signaling Interface (FC-PH 4.3). Through interswitch links (ISLs), the switch can connect additional switches to form a Fibre Channel multiswitch fabric.

The switch provides connectivity for devices manufactured by multiple original equipment manufacturers (OEMs). To determine if an OEM product can communicate through connections provided by the switch, or if communication restrictions apply, refer to the supporting publications for the product or contact your HP marketing representative.

## Features

The features of the Edge Switch 2/32 include:

- Scalable from 16 to 32 User ports
- 100% dynamic non-blocking, cut through switching with congestion queuing
- Online error detection, error isolation, and error recovery
- Redundant hot-pluggable components
- Small form factor, hot-pluggable optical transceivers

- Combination short-wave or long-wave laser transceivers
- Redundant power supplies and fan modules
- Online product repair for Field Replaceable Units (FRUs)
- Periodic health check and enhanced system monitoring
- Non-disruptive firmware load and update

## Switch management

The Edge Switch 2/32 is managed and controlled through the following user interfaces:

- High Availability Fabric Manager (HAFM appliance) with the Java™ based HAFM Element Manager installed. Access to the Element Manager must be through the HAFM applications. These applications are installed on the HAFM appliance.
- The Embedded Web Server (EWS) interface. Using a browser-capable PC and a connection to a LAN to which the switch is connected, you can monitor and manage the switch through the web server interface embedded in the switch firmware. The interface provides a GUI similar to the Element Manager application and supports switch configuration, statistics monitoring, and basic operation.

To launch the Embedded Web Server interface, enter the switch IP address as the internet uniform resource locator (URL) into any standard browser. Enter a user name and password at a the login screen. The browser then becomes a management console. Refer to the web server interface online help for details on use.



**NOTE:** The default user name for the right to view status and other information is operator. The default user name for the right to modify configuration data, perform maintenance tasks, or perform other options is Administrator. The default password for both user names is password.

---

- The command line interface (CLI). The CLI allows you to access many HAFM and Element Manager functions while entering commands during a Telnet session with the switch. The primary purpose of the CLI is to automate management of a large number of switches using scripts. The CLI is not an interactive interface; no checking is done for pre-existing conditions and no prompts display to guide users through tasks. Refer to the *HP StorageWorks CLI reference guide for directors and edge switches*.

This manual provides details on the Element Manager application for the Edge Switch 2/32 only. Use this manual for the Element Manager installed on an HAFM appliance.

## Error-Detection, reporting, and serviceability

The switch provides the following error-detection, reporting, and serviceability features:

- Light-emitting diodes (LEDs) on switch FRUs and adjacent to Fibre Channel ports that provide visual indicators of hardware status or malfunctions.
- System and threshold alerts, event logs, audit logs, link incident logs, threshold alert logs, and hardware logs that display switch, Ethernet link, and Fibre Channel link status at the HAFM appliance.

- Diagnostic software that performs power-on self-tests (POSTs) and port diagnostics (internal loopback, external loopback, and Fibre Channel (FC) loopback tests). The FC loopback test applies only when the switch is configured to operate in FICON management style.
- Automatic notification of significant system events (to support personnel or administrators) through e-mail messages or the call-home feature at the HAFM appliance.
- A modem for use by support personnel to dial-in to the HAFM appliance for event notification and to perform remote diagnostics.
- An RS-232 maintenance port at the rear of the switch (port access is password protected) that enables installation or service personnel to change the switch's internet protocol (IP) address, subnet mask, and gateway address. Or to run diagnostics and isolate system problems through a local or remote terminal.
- FRUs—small form factor pluggable (SFP) optical transceivers, power supplies, and cooling fans—that are removed or replaced without disrupting switch or Fibre Channel link operation.
- A modular design that enables quick removal and replacement of FRUs without tools or equipment.
- Concurrent port maintenance—SFPs and fiber-optic cables are removed and attached to ports without interrupting other ports or switch operation.
- Beaconing to assist service personnel in locating a specific port or switch. When port beaconing is enabled, the amber LED associated with the port flashes. When unit beaconing is enabled, the system error indicator on the front panel flashes. Beaconing does not affect port or switch operation.
- Data collection through the Element Manager on the HAFM appliance to help isolate system problems. The data includes a memory dump file and audit, hardware, and engineering logs.
- SNMP management:
  - Using the Fibre Alliance MIB (Version 3.1) that runs on the HAFM appliance, up to 12 authorized management workstations can be configured through the HAFM application to receive unsolicited SNMP trap messages.
  - Using the Fibre Channel Fabric Element MIB (Version 1.1), TCP/IP MIB-II definition (RFC 1213), or a product-specific MIB that runs on each switch, up to 6 authorized management workstations can be configured through the Element Manager to receive unsolicited SNMP trap messages.

The trap messages indicate operational state changes and failure conditions.



**NOTE:** For more information about SNMP support provided by HP products, refer to the *HP StorageWorks SNMP reference guide for directors and edge switches*.

---

## Zoning

The switch supports a name server zoning feature that partitions attached devices into restricted-access groups called zones. Devices in the same zone can recognize and communicate with each other through switched port-to-port connections. Devices in separate zones cannot communicate with each other.

Zoning is configured by authorizing or restricting access to name server information associated with device N\_Ports that attach to switch fabric ports (F\_Ports). A zone member is specified by the port number to which a device is attached, or by the eight-byte (16-digit) World Wide Name (WWN) assigned to the host bus adapter (HBA) or Fibre Channel interface installed in a device. A device can belong to multiple zones.

---

△ **CAUTION:** If zoning is implemented by port number, a change to the switch fiber-optic cable configuration disrupts zone operation and may incorrectly include or exclude a device from a zone.

If zoning is implemented by WWN, removal and replacement of a device HBA or Fibre Channel interface (thereby changing the device WWN) disrupts zone operation and may incorrectly include or exclude a device from a zone.

In Open Fabric mode, only zoning by WWN is supported. Zoning by port numbers is not.

---

Zones are grouped into zone sets. A zone set is a group of zones that is enabled (activated) or disabled across all switches in a multiswitch fabric. Only one zone set can be enabled at one time.

## Multiswitch fabrics

A Fibre Channel topology that consists of one or more interconnected switches or switch elements is called a fabric. Operational software provides the ability to interconnect switches (through expansion port (E\_Port) connections) to form a multiswitch fabric. The data transmission path through the fabric is typically determined by fabric elements and is user-transparent. Subject to zoning restrictions, devices attached to any interconnected switch can communicate with each other through the fabric.


## Hardware components

The switch provides a modular design that enables quick removal and replacement of FRUs—small form factor pluggable SFP optical transceivers, power supplies, and fans. This section describes the Edge Switch 2/32 main components.



## Front view

Figure 1 shows the front of the Edge Switch 2/32 and identifies the front panel components.




- |                                     |                     |
|-------------------------------------|---------------------|
| 1 Initial machine load (IML) button | 4 Port LEDs         |
| 2 Ethernet LAN connector            | 5 Error LED (amber) |
| 3 SFP fiber-optic connectors        | 6 Power LED (green) |

Figure 1 Edge Switch 2/32 (front view)

## Rear view

Figure 2 shows the rear of the Edge Switch 2/32. The FRUs on the rear panel include two power supplies and four individual cooling fan FRUs. Also shown on the rear panel is an RS-232 maintenance port (not labeled).



- |                    |  |
|--------------------|--|
| 1 Cooling fan (4)  | 3 Power switches on power supplies (2) |
| 2 Power supply (2) |  |

Figure 2 Edge Switch 2/32 (rear view)

## SFP transceivers (fiber optic connectors)

A single-mode or multimode fiber-optic cable attaches to a port through a small form pluggable (SFP) transceiver. The SFP provides a duplex LC interface, and can be detached from the switch port for easy replacement. Two fiber-optic transceiver types are available:

- Shortwave laser—Shortwave laser SFPs provide short-distance connections (2 to 500 meters) through 50-micron or 62.5-micron multimode fiber.
- Longwave laser—Longwave laser SFPs provide long-distance connections (up to 10 kilometers) through 9-micron single-mode fiber.
- Extended longwave laser—Extended longwave laser SFPs provide long-distance connections (up to 35 kilometers) through 9-micron single-mode fiber.

## Cooling fans

Four fans (each a separate FRU) provide cooling for the switch power supplies and the control processor (CTP) card, as well as redundancy for continued operation if a single fan fails.

Each fan FRU can be replaced while the switch is operating.

## Power supplies

Redundant, load-sharing power supplies step down and rectify facility input power to provide 3.3 volts direct current (VDC), 5 VDC, and 12 VDC to the CTP. The power supplies also provide input filtering, overvoltage protection, and overcurrent protection. Either power supply can be replaced while the switch is operational.

Each power supply has a separate CTP connection to allow for independent AC power sources. The power supplies are input-rated at 100 to 230 volts alternating current (VAC).

Power supply requirements are listed in.

## Connectors and indicators

Connectors and indicators include the:

- Initial machine load (IML) button.
- Ethernet LAN connector.
- Power and System Error LEDs (green power (PWR) and amber system error (ERR) LEDs).
- FRU status LEDs (green and amber status LEDs associated with FRUs).
- Maintenance port (RS-232).

## Initial machine load button

When the IML button ([Figure 1](#) on page 17) is pressed and held for three seconds, the switch performs an IML that takes approximately 30 seconds and resets the following:

- Microprocessor and functional logic for the CTP and loads firmware from FLASH memory.
- Ethernet LAN interface, causing the connection to the HAFM appliance to drop momentarily until the connection automatically recovers.

- Ports, causing all Fibre Channel connections to drop momentarily until the connections automatically recover.

An IML should only be performed if a CTP failure is indicated. Do not IML the switch unless directed to do so by a procedural step in this manual or by the next level of support. As a precaution, the IML button is flush mounted to protect against accidental activation.

## Ethernet LAN connector

The front panel provides a 10/100 megabit per second (Mbps) RJ-45 twisted-pair connector (Figure 1 on page 17) that attaches to an Ethernet LAN to provide communication with the on page 17 or an SNMP management workstation. Two green LEDs are associated with the LAN connector. When illuminated, the left LED indicates LAN operation at 10 Mbps, and the right LED indicates LAN operation at 100 Mbps.

## Power and system error LEDs

The PWR LED (Figure 1 on page 17) illuminates when the switch is connected to facility AC power and powered on. If the LED extinguishes, a facility power source, power cord, or power distribution failure is indicated.

The ERR LED (Figure 1 on page 17) illuminates when the switch detects an event requiring immediate operator attention, such as a FRU failure. The LED remains illuminated as long as an event is active. The LED extinguishes when the Clear System Error Light function is selected from the Element Manager. The LED blinks if unit beaconing is enabled. An illuminated ERR LED (indicating a failure) takes precedence over unit beaconing.

## FRU status LEDs

Amber and green LEDs associated with switch FRUs provide status information as follows:

- Port SFP—Amber and green LEDs to the left of the port (Figure 1 on page 17) illuminate, extinguish, or blink to indicate various port states (operational with active Fibre Channel traffic, operational but not communicating, beaconing, blocked, failed, inactive, or running diagnostics).
- Fan—An amber LED at the lower left corner of each fan (Figure 1 on page 17) illuminates if the fan fails or rotates too slowly.
- Power Supply—A green LED at the upper left corner of each power supply (Figure 2 on page 17) illuminates if the power supply is operational and receiving AC power.

## Maintenance port

The rear panel provides a 9-pin RS-232 maintenance port (Figure 2 on page 17) that provides a connection for a local terminal or dial-in connection for a remote terminal. Although the port is typically used by authorized maintenance personnel, operations personnel can use the port to configure switch network addresses.


## Tools and test equipment

This section describes tools and test equipment that may be required to install, test, service, and verify operation of the switch and attached on the HAFM appliance.

### Tools supplied with the switch


The following tools are supplied with the switch. Use of the tools may be required to perform one or more installation, test, service, or verification tasks. These tools are supplied with the switch or must be supplied by service personnel.

- Loopback plug—An SFP multi-mode (shortwave laser) or single-mode (longwave laser) loopback plug as shown in [Figure 3](#) is required to perform port loopback diagnostic tests. One loopback plug is shipped with the switch, depending on the type of port transceivers installed. Both plugs are shipped if shortwave laser and longwave laser transceivers are installed.




**Figure 3** Loopback plug

- Fiber-optic protective plug—For safety and port transceiver protection, fiber-optic protective plugs as shown in [Figure 4](#) on page 20 must be inserted in all switch ports without fiber-optic cables attached. The switch is shipped with protective plugs installed in all ports.



**Figure 4** Fiber-Optic protective plug

- Null modem cable—An asynchronous RS-232 null modem cable as shown in [Figure 5](#) is required to configure switch network addresses and acquire event log information through the maintenance port. The cable has nine conductors and DB-9 male and female connectors.



**Figure 5** Null modem cable

## Tools supplied by service personnel

The following tools are expected to be supplied by service personnel performing switch installation or maintenance actions. Use of the tools may be required to perform one or more test, service, or verification tasks.

- Scissors or pocket knife—A sharp cutting edge (scissors or knife blade) may be required to cut the protective strapping when unpacking replacement FRUs.
- Standard flat-tip and cross-tip (Phillips) screwdrivers—Screwdrivers are required to remove, replace, adjust or tighten various FRUs, chassis, or cabinet components.
- Electrostatic discharge (ESD) grounding cable with attached wrist strap—Use of the ESD wrist strap is required when working in and around the switch card cage.
- Maintenance terminal (desktop or notebook PC)—The PC is required to configure switch network addresses and acquire event log information through the maintenance port. The PC must have:
  - The Microsoft® Windows® 98, Windows 2000, Windows Server 2003, Windows XP, or Millennium Edition operating system installed.
  - RS-232 serial communication software (such as ProComm Plus or HyperTerminal) installed. HyperTerminal is provided with Windows operating systems.
- Fiber-optic cleaning kit—The kit contains tools and instructions to clean fiber optic cable, connectors, loopback plugs, and protective plugs.

## Optional kits

Contact your HP authorized service provider to purchase the following optional Edge Switch 2/32 kits. See [Table 2](#).

**Table 2** Edge Switch 2/32 optional kits

Supporting Kit	Description
8-flexport upgrade for the Edge Switch 2/32 Part Number: 302660-B21	Used to upgrade from 16 to 24 and from 24 to 32 ports.
Edge Switch 2/32 Element Manager license Part Number: 300658-B21	Used when switch is managed through HAFM.
HP Open Trunking License Part Number: 336000-B21	Provides a license to use the Open Trunking feature.
HP SANtegrity Binding License Part Number: 317071-B21	Provides a license to use the SANtegrity Binding feature.
300m Optical Transceiver Kit Part Number: 300834-B21	Provides short-wave optical transceiver for the Edge Switch 2/32.
10km Long Distance Optical Transceiver Kit. Part Number: 300835-B21	Provides 10 km long-wave optical transceiver for the Edge Switch 2/32.
35 km Extended Reach Optical Transceiver Kit Part Number: 300836-B21	Provides 35 km long-wave optical transceiver for the Edge Switch 2/32.

## 2 Installing and configuring the Edge Switch 2/32

This chapter describes tasks to install, configure, and verify operation of the Edge Switch 2/32. Some of the topics it covers include:

- [Review installation requirements](#), page 23
- [Unpack and inspect the switch](#), page 24
- [Install the Edge Switch on a desktop](#), page 25
- [Install the Edge Switch in a Rack](#), page 26
- [Configure switch network information](#), page 30
- [LAN-connect the switch](#), page 34
- [HAFM appliance](#), page 34
- [Frequently used HAFM settings](#), page 39
- [Connect the switch to a Fabric](#), page 65
- [Unpack, inspect, and install the Ethernet hub \(optional\)](#), page 67
- [Using HAFM from a remote location](#), page 67

### Installation options

The switch is installed in one of two configurations. The options are:

- Table or desktop—one or more switches, an optional HAFM appliance, and an optional Ethernet hub are installed at the customer facility on a desk or table top. Ethernet cabling distance, and local area network (LAN) addressing issues must be considered.
- Customer-supplied equipment rack—one or more switches, an optional HAFM appliance, and an optional Ethernet hub are installed in a customer-supplied equipment rack. Rack-mount hardware is provided in the shipping container. Ethernet cabling, distance, and LAN addressing issues must be considered.

### Review installation requirements

Verify that the following requirements are met prior to switch and HAFM appliance installation. Ensure that:

- A site plan is prepared, configuration planning tasks are complete, planning considerations are evaluated, and related planning checklists are complete. Fabric and device connectivity are evaluated, and the related planning worksheet is complete. Refer to the *HP StorageWorks HA-Fabric Manager User Guide*.
- Support equipment and personnel are available for the installation.
- The required number and type of fiber-optic jumper cables are delivered and available. Ensure that the cables are the correct length with the required connectors.
- Remote workstations or simple network management protocol (SNMP) workstations are available (optional). Workstations are customer-supplied and connected through a corporate or dedicated LAN.

Verify that the following items are present before beginning installation:

- (Optional). An HP 9000, HP 10000, HP 11000, HP M-Series, HP rack system/e, or an industry-standard 19-in rack.
- Two power outlets or different branches (for redundancy)
- Torque driver with cross-tip bit (for setting 22 in/lb. of torque)
- Fiber-optic protective plug—For safety and port transceiver protection, fiber-optic protective plugs must be inserted in all switch ports without fiber-optic cables attached.
- Null modem cable—An asynchronous RS-232 null modem cable is required to configure switch network addresses and obtain event log information through the maintenance port. The cable has nine conductors and two DB-9 female connectors. A null modem cable specially designed for this application is supplied with the Edge Switch 2/32.
- Standard flat-tip and cross-tip Phillips screwdrivers—Required to remove, replace, adjust or tighten various FRUs, chassis, or rack components.
- Electrostatic discharge (ESD) grounding cable with attached wrist strap—Required when working in and around the switch card cage.
- Maintenance terminal (desktop or notebook computer)—Required to configure switch network addresses and acquire event log information through the maintenance port. Computer requirements include:
  - Microsoft Windows 98, Windows Millennium Edition, Windows NT 4.0, Windows 2000, Windows Server 2003, or Windows XP operating system installed
  - RS-232 serial communication software (for example, ProComm Plus, or HyperTerminal).



**NOTE:** The HAFM appliance may be used for this function. The HyperTerminal application is included with the Windows operating system provided with the HAFM appliance.

---

## Unpack and inspect the switch

This section provides instructions for unpacking and inspecting the Edge Switch 2/32 and installing it in a desktop or rack-mount configuration.

To unpack and inspect the switch:

---

△ **CAUTION:** When you remove the switch from the carton, do not rest it on its rear window while examining it. To do so may break the FRU handles.

---

1. Inspect the shipping containers for damage caused during transit. If a container is damaged, ensure a representative from the freight carrier is present when the container is opened.
2. Unpack the shipping containers and inspect each item for damage. Save all shipping and packing materials. Ensure that all items on the enclosed shipping list are in each container.
3. If any items are damaged or missing, customers should contact an HP authorized service provider or reseller.



# Install the Edge Switch on a desktop

To install and configure the switch on a desktop:

1. Remove the backing from the four adhesive rubber pads and apply the pads to the underside of the switch. Ensure that the pads are aligned with the scribed circles at each corner.
2. Position the switch on a table or desktop as directed by the customer. Ensure:
  - Grounded AC electrical outlets are available.
  - Adequate ventilation is present.
  - Areas with excessive heat, dust, or moisture are avoided.
  - All planning considerations are met. Refer to the *HP StorageWorks HA-Fabric Manager user guide*.
3. Verify that all FRUs are installed as ordered.
4. Verify that the SFP optical transceivers are installed as required for your installation.
5. Connect the U.S. or country-specific (optional) AC power cords to the right (PS0) and left (PS1) receptacles at the rear of the chassis.

---

**⚠ WARNING!** An HP-supplied power cord is provided for each switch power supply. To prevent electric shock when connecting the switch to primary facility power, use only the supplied power cords, and ensure that the facility power receptacle is the correct type, supplies the required voltage, and is properly grounded.

---

6. Connect the remaining ends of the AC power cords to separate facility power sources that provide single-phase, 120 to 240 volt alternating current (VAC). This provides power redundancy.
7. Turn on the power. Two power switches are on the back of the unit. Turn on both switches. The unit powers on and performs power-on self-tests (POSTs). During POSTs:
  - a. The green power (PWR) LED on the front panel turns on.
  - b. The amber system error (ERR) LED on the front panel flashes momentarily while the switch is tested.
  - c. The green LEDs associated with the Ethernet port flash momentarily while the port is tested.
  - d. The green and amber LEDs associated with the ports flash momentarily while the ports are tested.
8. After successful POST completion, the green power (PWR) LED remains on and all other front panel LEDs turn off.
9. If a POST error or other malfunction occurs, refer to the *HP StorageWorks Edge Switch 2/32 service manual* to isolate the problem.

## Install the Edge Switch in a Rack


This section describes how to rack mount the HP StorageWorks Edge Switch 2/32 in the appropriate HP, or comparable, 19-inch Electronic Industries Association (EIA) rack:

- HP 9000 series, 10000 series and 11000 series racks
- HP rack system/e or 19-inch EIA rack

### Rack mount checklist

This section describes the contents of the rack mount kit as well as tools or equipment required to complete the installation.

---

 **NOTE:** The hardware kit includes parts not required for the configuration described in these instructions.

---

### Mounting hardware


- Two (2) two-hole bar nuts
- Six (6) three-hole bar nuts (only 4 used)
- Eight (8) square alignment washers (required only for HP 9000, 10000 and 11000 series racks)
- Eight (8) Phillips panhead screws (10-32 x 1/2) with split lock and flat washers
- Four (4) Phillips flathead screws (8-32 x 7/16)
- Ten (10) Phillips panhead screws (10-32 x 5/8) with flat washer (only 2 used)
- Six (6) Phillips flathead screws (6-32 x 3/8) (not used)
- Twelve (12) Phillips panhead screws (10-32 x 3/8) (not used)
- Four (4) 8-32 Keps nuts (not used)

### Brackets and rails

Brackets and rails included in the kit are shown in [Figure 6](#).

- ❶ Two (2) fixed-length slide rails (one left and one right)
- ❷ Two (2) Front brackets
- ❸ Two (2) Rear brackets (long)
- ❹ Two (2) Rear spacing bracket

⑤ Rear bracket (short)—not used in this configuration



**Figure 6** Brackets included in kit

## Required tools


The following tools are required, but are not included in the kit:

- Torque driver with a T10 Torx bit
- #2 Phillips screwdriver

## Mounting the adjustable brackets in the rack

Use these steps to install the adjustable brackets on the rack. You will need a #2 Phillips screwdriver and eight 10x32 panhead screws to complete this procedure.

---


 **NOTE:** If you are installing the Edge Switch 2/32 in an HP 9000, 10000 or 11000 series rack, you will need eight square alignment washers to complete this procedure.

---

1. Determine the position of the switch in the rack. Each Edge Switch 2/32 is 1.75 inches or 1U high.

2. Attach four bar nuts (three-hole bar nuts) to the cabinet frame using eight (8) Phillips panhead screws (10-32 x 1/2) with split lock and flat washers.

---

 **NOTE:** Do not install a screw in the center hole of each bar nut.

---

- a. If you are installing the Edge Switch 2/32 in an HP 9000, 10000 or 11000 series rack, place a square alignment washer on each panhead screw before inserting in the square cabinet frame holes.
  - b. Mount the bar nut on the inside of the cabinet frame. Orient the holes in the bar nut so that they are aligned closest to the inside edge of the cabinet frame.
  - c. Secure, but do not completely tighten, all screws.
3. Measure cabinet depth from inside edge to inside edge of the cabinet frame.
  4. Assemble two sets of front and rear brackets so that the combined brackets are equal to the depth of the cabinet.
  5. Attach a two-hole bar nut using four (4) Phillips flathead screws (8-32 x 7/16) to hold each assembled bracket together. Do not completely tighten but tighten enough to hold the brackets together.
  6. Install the assembled brackets in the cabinet by sliding the mounting brackets between the bar nut and cabinet frame.
  7. Tighten the three-hole bar nut screws on the mounting brackets to where the rails are stable, but can be easily adjusted.
  8. Securely tighten the two-hole bar nut screws holding the front and rear brackets together.

## Mounting the slide rails on the sides of the switch


Use these steps to install the slide rails on the sides of the switch as shown in [Figure 7](#). You will need a torque driver with a T10 Torx bit (not supplied in the kit) and left and right slide rails to complete this procedure.

---

 **NOTE:** You may want to remove the Edge Switch 2/32 power supplies, as this will make the device lighter and easier to handle.

---


---

 **WARNING!** Before removing the power supplies, review the *HP StorageWorks Edge Switch 2/32 service manual* for details on removing power supplies.

---


1. On the Edge Switch 2/32, remove the six screws (three screws per side) that help hold the switch cover in place.

---

 **NOTE:** Do not discard these screws, as you will use them to attach the slide rails.

---

2. Using the torque driver and the screws you removed earlier, attach the left and right slide rails to the Edge Switch 2/32.



**Figure 7** Attaching the slide rail to the switch

## Installing the switch in the cabinet

Use these steps to install the switch in the cabinet. You will need a #2 Phillips screwdriver and two rear spacing brackets to complete this procedure.


1. From the front side of the cabinet, slide the switch into the mounting brackets and along the rails until the rear of the switch is flush with the rear of the cabinet.
2. Bring the rear spacing brackets to the rear of the cabinet.
3. Pull the switch toward the rear of the cabinet until it protrudes approximately 3 inches.
4. Orient the rear spacing bracket mounts so that they are pointed outward. Insert the tabs on each rear spacing bracket into the designated slots in each rail.
5. Push the switch forward using both rear spacing brackets until the rear spacing bracket mounts contact the cabinet rail.
6. Attach the rear spacing brackets to the cabinet using two Phillips panhead screws (10-32 x 5/8) with flat washer.
7. Ensuring that the square alignment washers are seated properly within the square cabinet frame holes, use a Phillips head screwdriver to tighten the rear and front mounting screws.

## Configure switch network information

The Edge Switch 2/32 is delivered with the following default network addresses:

- MAC address—the media access control (MAC) address is programmed into FLASH memory on the CTP card at the time of manufacture. The MAC address is unique for each switch, and should not be changed. The address is in xx.xx.xx.xx.xx.xx format, where xx is a hexadecimal pair.

---

 **NOTE:** References to the CTP in this manual are to the control processor logic contained on the switch motherboard. If an event occurs that indicates the CTP as faulty, replacement of the switch assembly is required.


---

- IP address—the factory preset default internet protocol (IP) address is 10.1.1.10. The default IP address is also 10.1.1.10.


If Reset Configuration is selected from the Element Manager application, the switch resets to the default address of 10.1.1.10.

If multiple switches are installed on the same LAN, each switch (and the HAFM appliance) must have a unique IP address. One switch can use the factory-set address, but the addresses of the remaining switches must be changed.

---

 **NOTE:** If you have enabled additional port function with the HP Flexport feature since the switch shipped from the factory, resetting the configuration will return this feature to the factory default of only 16 ports enabled. You must re-enable the additional ports using the Configure Feature Key dialog box (see “[Configure feature key](#)” on page 64).

---

 **WARNING!** This operation resets all configuration including any optional features that have been installed. You will need to re-enter your feature key to enable all optional features after resetting the configuration parameters.

---

- Subnet mask—the default subnet mask is 255.0.0.0. If the switch is installed on a complex public LAN with one or more routers, the address may require change.
- Gateway address—the default gateway address is 0.0.0.0. If the switch is installed on a dedicated LAN with no connection through a router, the address does not require change. If the switch is installed on a public LAN (corporate intranet), the gateway address must be changed to the address of the corporate intranet’s local router.

Verify that the type of LAN installation with the customer’s network administrator. If one switch is installed on a dedicated LAN, network addresses do not require change.

## Changing the switch address

If multiple switches are installed or a public LAN segment is used, network addresses must be changed to conform to the customer's LAN addressing scheme. The following items are required to perform this task:

- A local workstation (desktop or notebook computer) with:
  - Microsoft Windows 98, Windows 2000, Windows Server 2003, Windows XP, or Windows NT 4.0 operating system.
  - RS-232 serial communication software (for example, ProComm Plus or HyperTerminal).Note that the HAFM appliance may be used for this function and that HyperTerminal is included with Windows 2000 or Windows Server 2003 provided in the HAFM appliance.
- An asynchronous RS-232 null modem cable (provided with the switch).

Perform the following steps to change a switch's IP address, subnet mask, or gateway address:

1. Remove the protective metal plate from the 9-pin maintenance port at the rear of the switch (a Phillips-tip screwdriver is required). Connect the 9-pin end of the RS-232 null modem cable to the port.
2. Connect the other cable end to a 9-pin communication port (COM1 or COM2) at the rear of the maintenance terminal PC.
3. Power on the maintenance terminal. After the PC powers on, the Windows desktop is displayed. Refer to operating instructions shipped with the PC.



**NOTE:** Procedures for changing network addresses using the HyperTerminal serial communication software are described in [step 4](#) through [step 13](#).

4. Select **Start > Programs > Accessories > Communications > HyperTerminal**. The Connection Description dialog box is displayed, ([Figure 8](#)).




**Figure 8** Connection Description dialog box

5. Enter **edge switch 2-32** in the Name field and click **OK**. The Connect To dialog box is displayed (Figure 9).



**Figure 9** Connect To dialog box

6. Ensure that the Connect using field displays **COM1** or **COM2** (depending on the serial communication port connection to the switch), and click **OK**. The Port Settings dialog box is displayed (Figure 10).



**Figure 10** Port Settings dialog box


7. Enter the Port Settings parameters as follows:

- Bits per second—**115200**
- Data bits—**8**
- Parity—**None**
- Stop bits—**1**
- Flow control—**Hardware**

When the parameters are set, click **OK**. The HyperTerminal window is displayed.



8. At the `>` prompt, enter the user-level password (the default is `password`) and press **Enter**. The password is case sensitive. The HyperTerminal window is displayed with a `C>` prompt at the top of the window (Figure 11).



**Figure 11** HyperTerminal window

9. At the `C>` prompt, enter **ipconfig** and press **Enter**. The HyperTerminal window is displayed with configuration information listed as follows:

- MAC Address
- IP Address (default is 10.1.1.10, factory preset is 10.1.1.10)
- Subnet Mask (default is 255.0.0.0).
- Gateway Address (default is 0.0.0.0)

Only the IP Address, Subnet Mask, and Gateway Address fields are configurable.


10. Change the IP address, subnet mask, and gateway address as directed by the customer's network administrator. To change switch network addresses, enter the following at the `C>` prompt:

```
ipconfig xxx.xxx.xxx.xxx yyy.yyy.yyy.yyy zzz.zzz.zzz.zzz
```

The IP address is always `xxx.xxx.xxx.xxx`, the subnet mask is always `yyy.yyy.yyy.yyy`, and the gateway address is always `zzz.zzz.zzz.zzz`. The octets `xxx`, `yyy`, and `zzz` are decimals from zero through 255. If a network address is to remain unchanged, type the current address in the respective field.


When the new network addresses are configured at the switch, the message `Request completed OK` is displayed at the bottom of the Edge Switch 2/32—HyperTerminal window.

11. Select **File > Exit** close the HyperTerminal application. A message box is displayed (Figure 12).



**Figure 12** Disconnect Now dialog box

12. Click **Yes**. A message box is displayed (Figure 13).



**Figure 13** Save Session dialog box

13. Click **No** to exit and close the HyperTerminal application.

14. Power off the maintenance terminal:

- a. Select **Start > Shut Down**. The Shut Down Windows dialog box is displayed.
- b. Select **Shut Down Windows > Shut down the Computer** and click **Yes** to power off the PC.

15. Disconnect the RS-232 null modem cable from the switch and the maintenance terminal. Replace the plastic cover over the maintenance port.

## LAN-connect the switch

Connect the switch to the Ethernet LAN segment or the HP-supplied Ethernet hub.

To connect the desktop or rack-mounted switch to the Ethernet LAN segment:

1. Connect one end of the Ethernet patch cable (supplied with the switch) to the RJ-45 connector (labeled 10/100) on the left front of the chassis.
2. Connect the remaining end of the Ethernet cable to the LAN as follows:
  - a. If the switch is installed on a customer-supplied LAN segment, connect the cable to the LAN as directed by the customer's network administrator.
  - b. If the switch is installed on the HP-supplied Ethernet hub, connect the cable to any available port on the hub.
3. Perform one of the following steps:
  - If an HAFM appliance is delivered and available, go to "[HAFM appliance](#)" on page 34.
  - If an HAFM appliance is not available and the switch is managed through the Embedded Web Server interface, attach the Ethernet LAN segment to an internet connection and go to "[Using the Embedded Web Server](#)" on page 71.

## HAFM appliance

To run HAFM software, you must set up and configure the HAFM appliance. Refer to the *HP StorageWorks HA-Fabric Manager appliance installation guide* for instructions on:

- Setting up the HAFM appliance.
- Connecting the HAFM appliance to the LAN.
- Configuring the network addressing for the HAFM appliance.
- Setting the HAFM appliance date and time.
- Creating HAFM user names and passwords.

# Record or verify HAFM appliance restore information

Configuration information must be recorded to restore the HAFM appliance in case of hard drive failure. The Windows operating system and the HAFM and Element Manager application must also be restored. Refer to the *HP StorageWorks HA-Fabric Manager appliance installation guide* for instructions.

To record or verify HAFM appliance configuration information, refer to the appropriate HAFM appliance installation for instructions.

## Enabling HAFM to manage the switch

To manage a new switch, it must be identified to the HAFM appliance. To identify the new switch:

- 1. At the HAFM application (Element manager or EWS main window), select **Setup** from the Discover menu. The Discover Setup dialog box is displayed (Figure 14).




Figure 14 Discover Setup dialog box

- 2. Click **Add**. The Domain Information dialog box is displayed with the IP Address page open by default (Figure 15).




Figure 15 Domain Information dialog box (IP Address page)

- 3. Enter a switch description (for example, **edge-32**) the Description field.





4. Enter the switch IP address (determined by the customer's network administrator) in the IP Address field.
5. Enter the switch subnet mask (determined by the customer's network administrator) in the Subnet Mask field.
6. At the Data Source for Domain area of the dialog box, select the Use auto detection, Use the server, or Use a specific RDC radio button (determined by the customer's network administrator).
7. Click **OK** to save the entered information, close the dialog box, and define the switch to the HAFM application.
8. Repeat [step 2](#) through [step 7](#) for each new switch.
9. Click **OK** to close the Discover Setup dialog box and return to the HAFM application.

## Verify Communication between the switch and the HAFM appliance

Communication must be verified between the switch and the HAFM appliance Element Manager and EWS applications. To verify switch-to-appliance communication:


1. At the management application's main window (physical map or product list), inspect the shape and color of the status symbol associated with the Edge Switch product icon. [Table 3](#) explains the symbols and associated operational states.

**Table 3** Switch operational states and symbols

Operational state	Symbol
Operational—switch-to appliance communication is established, the switch is operational, and no failures are indicated. Go to <a href="#">"Set Switch date and time"</a> on page 38. (	
Degraded—switch-to-appliance communication is established, but the switch is operating in degraded mode and requires service. This condition is typical if a port or redundant FRU fails. Go to <a href="#">step 2</a> .	
Failed—switch-to appliance communication is established, but the switch failed and requires immediate service. Go to <a href="#">step 2</a> .	
Status Unknown—the switch status is unknown because of a network communication failure between the switch and HAFM appliance. Go to <a href="#">step 2</a> .	

2. Right-click the switch icon at the HAFM application's physical map. A pop-up menu appears.

3. Select **Element Manager** from the pop-up menu. When the Element Manager application opens, the last view (tab) accessed by a user opens by default. The example in [Figure 16](#) shows the Hardware View.




**Figure 16** Switch Hardware View page

4. Inspect switch status at the Hardware View page and perform one of the following steps:
  - a. If the switch displays the Operational state (no FRU alert symbols and a green circle at the alert panel), go to ["Set Switch date and time"](#) on page 38.
  - b. If the switch displays the Degraded state or a switch failure is indicated (FRU alert symbols and a yellow triangle or red diamond at the alert panel), refer to the *HP StorageWorks Edge Switch 2/32 service manual* to isolate the problem.

## Set Switch date and time

The Edge Switch 2/32 Element Manager log entries are stamped with the date and time received from the switch. To set the effective date and time for the switch:

1. At the Hardware View page for the selected switch, select **Configure > Date/Time**. The Configure Date and Time dialog box is displayed (Figure 17).



**Figure 17** Configure Date and Time dialog box

The switch date and time can be set manually, or set to be periodically updated by the HAFM appliance (the switch and HAFM appliance synchronize at least once daily).

## Set date and time manually

To set the switch date and time manually:

1. At the Configure Date and Time dialog box, click **Periodic Date/Time Synchronization** to deselect the option (no check mark in the box). The greyed out Date and Time fields activate.
2. Click the Date fields that require change, and enter numbers in the following ranges:  
Month (MM): 1 through 12  
Day (DD): 1 through 31  
Year (YY): greater than 1980
3. Click the Time fields that require change, and enter numbers in the following ranges:  
Hour (HH): 0 through 23  
Minute (MM): 0 through 59  
Second (SS): 0 through 59
4. Click **Activate** to set the switch date and time and close the Configure Date and Time dialog box.

## Periodically synchronize date and time

To set the switch to periodically synchronize date and time:


1. Click **Periodic Date/Time Synchronization** to select the option (check mark in the box). The Date and Time fields are greyed out and not selectable. Perform one of the following options:
  - Click **Activate** to enable synchronization and close the Configure Date and Time dialog box. The switch date and time synchronize with the HAFM appliance date and time at the next update period (at least once daily).
  - Click **Sync Now** to synchronize the switch and HAFM appliance immediately. The Date and Time Synced dialog box is displayed.

2. Click **OK** to synchronize the date and time and close the Date and Time Synced dialog box, then click **Activate** to enable synchronization and close the Configure Date and Time dialog box.

## Frequently used HAFM settings

This section summarizes the most common HAFM tasks, including:

---

 **NOTE:** For a complete reference on HAFM functionality, refer to the *HP StorageWorks HA-Fabric Manager user guide*.

---

- [Set the switch online](#), page 39
- [Set the switch offline](#), page 40
- [Configure switch identification](#), page 40
- [Configure switch management style](#), page 41
- [Configure Switch Operating Parameters](#), page 42
- [Configure fabric operating parameters](#), page 44
- [Configure switch binding](#), page 47
- [Configure ports \(Open Systems management style\)](#), page 47
- [Configure ports \(FICON management style\)](#), page 51
- [Configure port addresses \(FICON\)](#), page 52
- [Configure SNMP trap message recipients](#), page 53
- [Configure, enable, and test e-mail notification](#), page 54
- [Configure and enable call-home features](#), page 56
- [Configure and enable ethernet events](#), page 56
- [Configure threshold alerts](#), page 57
- [Configure Open Systems management appliance](#), page 64
- [Configure FICON management appliance](#), page 64
- [Configure feature key](#), page 64
- [Configure Open Trunking](#), page 64
- [Enable Embedded Web Server](#), page 64
- [Enable Telnet](#), page 64

## Set the switch online

When the switch is set online, an attached device can log into the switch if the port is not blocked. Attached devices can communicate with each other if they are configured in the same zone. Use these steps to set the switch online:

1. Open HAFM. The Products View page is displayed.
2. Double-click the appropriate switch icon. The Hardware View page for the selected switch is displayed.

3. Select **Maintenance > Set Online State**. If the switch is offline, the Set Online State dialog box is displayed, indicating the status is offline.
4. Click **Set Online**. A Warning dialog box is displayed, indicating status is online.
5. Click **OK**. The Status table displays *Online*.

## Set the switch offline

When the Edge Switch 2/32 is set offline, all ports are set offline. The switch transmits the offline sequence (OLS) to attached devices, and the devices cannot log in to the switch. Use these steps to set the switch offline:


1. Notify the customer that the switch is going offline.
2. Open HAFM. The Products View page is displayed.
3. Select the appropriate switch icon. The Hardware View page for the selected switch is displayed.
4. Select **Maintenance > Set Online State**. If the switch is online, the Set Online State dialog box is displayed, indicating the status is *Online*.
5. Click **Set Offline**. A Warning dialog box is displayed, indicating the switch will be set offline.
6. Click **OK**.

## Configure switch identification

Perform this procedure to configure the switch name, description, location, and contact person for the HAFM application. The information is displayed in multiple dialog boxes throughout the application. In addition, the *Name*, *Location*, and *Contact* variables configured at the Configure Identification dialog box correspond respectively to the SNMP variables *sysName*, *sysLocation*, and *sysContact*. These variables are used by SNMP management workstations when obtaining data from managed switches.

To configure the switch identification:

1. At the Hardware View page for the selected switch, select **Configure > Identification**. The Configure Identification dialog box is displayed (Figure 18).



**Figure 18** Configure Identification dialog box


- a. Type a switch name of 24 or fewer alphanumeric characters in the **Name** field. Each switch should be configured with a unique name.  
If the switch is installed on a public LAN, the name should reflect the switch's Ethernet network DNS host name. For example, if the DNS host name is *hpes232.hp.com*, enter **hpes232**.
- b. Click **Set Name as Nickname** and add a check mark if you want to use the name in the name field as the nickname for the switch's WWN. The nickname will display instead of the WWN in Element Manager views.



- c. Type a switch description of 255 or fewer alphanumeric characters in the Description field.
  - d. Type the switch's physical location (255 or fewer alphanumeric characters) in the Location field.
  - e. Type the name of a contact person (255 or fewer alphanumeric characters) in the Contact field.
2. Click **Activate** to configure the switch identification and close the dialog box.

## Configure switch management style


---

 **NOTE:** To change this value, you must first set the switch offline (see "[Set the switch offline](#)" on page 40). After you change the value, be sure to set the switch online again (see "[Set the switch online](#)" on page 39.)

---

Perform this procedure to set the switch to Open Systems or FICON management style. This setting only affects the management style used to manage the switch; it does not affect port operation. That is, OSI devices can communicate with each other if the switch is set to FICON management style; FICON devices can communicate with each other if the switch is set to Open Systems management style.

---

 **NOTE:** If the FICON management appliance feature is enabled, the default management style is FICON and the Open Systems management style cannot be enabled.

---

Typically, FICON management style is used when attaching an IBM S/390 Parallel Enterprise or IBM zSeries server to the switch and implementing inband switch management through a Fibre Connection (FICON) channel.

To configure the switch management style:

1. Ensure that the switch is set offline. For instructions, see "[Set the switch offline](#)" on page 40.
2. Select **Product > Management Style**. The Configure Management menu is displayed.
3. Select the management style as follows:
  - **Open Systems**— Use for all non-FICON Fibre Channel environments.
  - **FICON**—If the FICON management appliance feature is enabled, the default style will be FICON. You will not be able to change to Open Systems with the FICON management appliance feature enabled.
4. Click **Activate**.
5. Set the switch online. For instructions, see "[Set the switch online](#)" on page 39.

## Configure Switch Operating Parameters

Use the procedures in this section to set parameters on the switch for fabric operation through the Configure Switch Parameters dialog box. These operating parameters are stored in NVRAM on the switch.


1. The switch must be offline to change the Preferred Domain ID and other operating parameters. Ensure that the switch is set offline. For instructions, see ["Set the switch offline"](#) on page 40.

---

△ **CAUTION:** Setting the switch offline terminates all Fibre Channel connections.


---

2. Select **Configure > Operating Parameters > Switch Parameters**. The Configure Switch Parameters dialog box is displayed ([Figure 19](#)).



**Figure 19** Configure Switch Parameters dialog box

---

 **NOTE:** Ordinarily, you do not need to change values in this dialog box from their defaults. The only exception is the Preferred Domain ID. Change this value if the switch will participate in a multiswitch fabric.

---

3. Use information in the ["Switch parameters"](#) section, which follows, to change settings as required for parameters in this dialog box.
4. After you change settings, click the **Activate** button.
5. Set the switch online. For instructions, see ["Set the switch online"](#) on page 39.

### Switch parameters


Configure the following parameters as required by your fabric.

#### Domain ID

The domain identification is a value from 1 through 31 that provides a unique identification for the switch in a fabric. An Edge Switch cannot contain the same domain ID as another switch or their E\_Ports will segment when they try to join.

In the Configure Switch Parameters dialog box, a field is provided to enter a preferred domain ID and a check box is provided to enable this ID as an insistent domain ID.

## Preferred

 **NOTE:** To change this value, you must first set the switch offline. Select **Set Online State** from the Maintenance menu to display the Set Online State dialog box, then click the button. Be sure to set the switch back online after you change this value.

---

Use this field to set a unique domain ID for the switch. The default value is 1. Set a value from 1 through 31. When a switch comes online with a preferred ID, it requests an ID from the fabric's principal switch (indicating its preferred value as part of the request). If the requested domain ID is not allocated to the fabric, the domain ID is assigned to the requesting switch. If the requested domain ID is already allocated, an unused domain ID is assigned. Note that you must set the switch offline before you can change to the preferred domain ID.

The preferred domain ID must be unique for each director and switch in a fabric. If two switches or directors have the same preferred domain ID, the E\_Ports segment, causing the fabric to segment.


For more information on domain ID, refer to the section on domain ID assignment for multiswitch fabrics in the *HP StorageWorks HA-Fabric Manager User Guide* for details.

## Insistent

This option is not supported unless the SANtegrity feature is installed. Click the check box to remove or add a check mark. The default state is disabled (no check mark).

When a check mark is displayed, the domain ID configured in the Preferred Domain ID field will become the active domain identification when the fabric initializes. See the following notes:

- This option is required if the HAFM is enabled.
- If you enable Insistent Domain while the switch or director is online, the Preferred Domain ID will change to the current active domain ID if the IDs are different.

 **CAUTION:** If a switch with a duplicate domain ID exists in the fabric, both switches' E\_Ports will segment when they try to join.

---

## Rerouting Delay

Placing a check mark in the check box to the left of the Rerouting Delay option enables rerouting delay. This option is only applicable if the configured switch is in a multiswitch fabric. The default state is enabled.

Enabling the rerouting delay ensures that frames are delivered in order through the fabric to their destination. If there is a change to the fabric topology that creates a new path (for example, a new switch is added to the fabric), frames may be routed over this new path if its hop count is less than a previous path with a minimum hop count. This may result in frames being delivered to a destination out of order since frames sent over the new, shorter path may arrive ahead of older frames still in route over the older path.

If rerouting delay is enabled, traffic ceases in the fabric for the time specified in the E\_D\_TOV field of the Configure Fabric Parameters dialog box. This delay allows frames sent on the old path to exit to their destination before new frames begin traversing the new path.

---

 **NOTE:** This option is required if High Availability Fabric Manager (HAFM) is enabled.

---

## Domain RSCNs

Domain register for state change notifications (domain RSCNs) are sent between end devices in a fabric to provide additional connection information to host bus adapters (HBA) and storage devices. As an example, this information might be that a logical path has been broken because of a physical event, such as a fiber-optic cable being disconnected from a port. Consult with your HBA and storage device vendor to determine if enabling Domain RSCNs will cause problems with your HBA or storage products. Note that this option is required if Enterprise Fabric Mode (optional SANtegrity binding feature) is enabled.

## Suppress RSCNs on zone set activations

Fabric format domain register for state change notifications (RSCNs) are sent to ports on the switch following any change to the fabric's active zone set. These changes include activating and deactivating the zone set, or enabling and disabling the default zone. When the Suppress RSCNs on zone set activations check box is selected, fabric format RSCNs are not sent for zone changes to the attached devices on the switch. Click the check box to remove or add a check mark.


This option is enabled (check box not selected) by default. In most cases this option should be enabled so that attached devices can receive notification of zoning changes in the fabric. However, some HBAs may log out, then log back into the fabric when they receive an RSCN, thereby disrupting Fibre Channel traffic. Consult with your HBA and storage device vendor to determine if disabling this option (and thereby enabling RSCN transmission) will cause problems with your HBA or storage products.

## Configure fabric operating parameters

Use procedures in this section to set parameters on the switch for fabric operation through the Configure Fabric Parameters dialog box. These operating parameters are stored in NV-RAM on the switch.


1. The switch must be offline to change parameters in this dialog box. Ensure that the switch is set offline. For instructions, see "[Set the switch offline](#)" on page 40.

---

 **CAUTION:** Setting the switch offline terminates all Fibre Channel connections.


---

2. At the Hardware View, select **Operating Parameters > Fabric Parameters** from the Element Manager window. The Configure Fabric Parameters dialog box is displayed (Figure 20).



**Figure 20** Configure Fabric Parameters dialog box

---

 **NOTE:** Ordinarily, you do not need to change values in this dialog box from their defaults. The only exception is the Preferred Domain ID. Change this value if the switch will participate in a multiswitch fabric.

---

3. Use information under “[Fabric parameters](#)” on page 45 to change settings as required for parameters in this dialog box.
4. After you change settings, click **Activate**.
5. Back up the configuration data when you are finished configuring the switch.
6. Set the switch online. For instructions, see “[Set the switch online](#)” on page 39.

## Fabric parameters

Configure the following parameters as required by your fabric.


### BB\_Credit

Configure the switch to support buffer to buffer credit (BB\_Credit) from 1 through 60. This is the value used for all ports, except those configured for extended distance buffering (10-100 km). The default value is 16. For a description of the buffer-to-buffer credit, refer to the industry specification, *Fibre Channel Physical and Signaling Interface*.

### R\_A\_TOV

Configure resource allocation time-out value (R\_A\_TOV) in tenth-of-a-second increments. This variable works with the error detect time-out value (E\_D\_TOV) variable to control the switch’s behavior when an error condition occurs. Resources are allocated to a circuit when errors are detected and are not released for reuse until the time set by the R\_A\_TOV value expires. The default value is 100 tenths (10 seconds). Set a value from 10 tenths through 1200 tenths (1 through 120 seconds).

---


 **NOTE:** Set the same value for R\_A\_TOV on all directors and switches in a multiswitch fabric. If the value is not the same on all units, the fabric segments. Also, the value for R\_A\_TOV must be greater than the value configured for E\_D\_TOV.

---

## E\_D\_TOV

Adjust the E\_D\_TOV in tenth-of-a-second increments. An error condition occurs when an expected response is not received within the time limit set by this value. The default value is 20 tenths (2 seconds). Set a value from 2 tenths through 600 tenths (.2 through 60 seconds).

---

 **NOTE:** Set the same value for E\_D\_TOV on all switches and directors in a multiswitch fabric. If the value is not the same, the fabric segments.

---

## Switch priority

Setting this value determines the principal switch for the multiswitch fabric. Select **Principal** (highest priority), **Default**, or **Never Principal** (lowest priority) from the Switch Priority drop-down list.


Setting these priority values determines the principal switch selected for the multiswitch fabric. For example, if you have three switches in the fabric and set one as Principal, one as Default, and one as Never Principal, the unit set to Principal becomes the principal switch in the fabric.

If all switches are set to Principal or Default, the switch with the highest priority and the lowest WWN becomes the principal switch. Following are some examples of principal switch selection when switches have these settings:

- If you have three switches and set all to Default, the switch with the lowest WWN becomes the principal switch.
- If you have three switches and set two to Principal and one to Default, the switch with the Principal setting that has the lowest WWN becomes the principal switch.
- If you have three switches and set two to Default and one to Never Principal, the switch with the Default setting and the lowest WWN becomes the principal switch.

At least one switch in a multiswitch fabric needs to be set as Principal or Default. If all of the switches are set to Never Principal, all of the interswitch links (ISLs) will segment. If all but one switch is set to Never Principal and the switch that was principal goes offline, then all of the other ISLs will segment.

---

 **NOTE:** HP recommends that you leave the switch priority setting as Default. If you are considering setting this value to something other than default, refer to the section on principal switch selection for multiswitch fabrics in the *HP StorageWorks HA-Fabric Manager user guide* for details.

---

In, for example, the audit log, you may notice that the Principal setting maps to a number code of 1, Default maps to a number code of 254, and Never Principal maps to a number code of 255. The number codes of 2-253 are not currently in use.

## Interop Mode

Select one of the following options:

- **Homogeneous Fabric**—Select this mode if the fabric contains only HP directors and switches that are operating in Homogeneous Fabric mode.
- **Open Fabric 1.0**—Default. Select this mode if the fabric contains HP directors and switches, as well as other open-fabric compliant switches. Select this mode for managing heterogeneous fabrics.

## Configure switch binding

This feature is managed through the Switch Binding submenu options available on the Element Manager Configure menu. Using Switch Binding, you can specify devices and switches that can attach to director and switch ports. This provides security in environments that include a large number of devices by ensuring that only the intended set of devices attach to a switch or director. For complete procedures on configuring this optional feature, refer to the *HP StorageWorks Edge Switch Element Manager user guide*.

## Configure ports (Open Systems management style)

If the switch is set to Open Systems management style, perform this procedure to define Fibre Channel port names, configure ports as blocked or unblocked, enable extended distance operation and link incident (LIN) alerts, configure port binding, and define port types.


To configure switch ports (Open Systems management style only):

1. At the Hardware View page for the selected switch, select **Configure > Ports**. The Configure Ports dialog box (Open Systems management style) is displayed.
  - a. Select a blank Name field and enter a descriptive port name of 24 or fewer alphanumeric characters. Use a name that reflects the device connected to the port.
  - b. Click the **Blocked** check box to block or unblock a port. A check mark in the box indicates the port is blocked. Blocking the port prevents the attached device from communicating with the switch. A blocked port continuously transmits the offline sequence (OLS) (Figure 21).

Port #	Name	Blocked	RX BB Credit	LIN Alerts	Type	Speed	Port Binding	Bound VMMN
0		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:00:08:00:20:00:00:00
1		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:01:00:60:48:00:00:00
2		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:02:00:00:C9:00:00:00
3		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:03:00:60:48:00:00:00
4		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:04:00:00:C9:00:00:00
5		<input type="checkbox"/>	16	<input type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:05:00:E0:69:00:00:00
6		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:06:00:E0:69:00:00:00
7		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:07:00:60:48:00:00:00
8		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:08:00:E0:69:00:00:00
9		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:09:08:00:20:00:00:00
10		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:0A:08:00:20:00:00:00
11		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:0B:08:00:20:00:00:00
12		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:0C:00:00:C9:00:00:00
13		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:0D:00:00:C9:00:00:00
14		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:0E:00:60:48:00:00:00
15		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:0F:00:00:C9:00:00:00
16		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:10:00:60:48:00:00:00
17		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:11:00:00:C9:00:00:00
18		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:12:00:60:48:00:00:00
19		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:13:00:00:C9:00:00:00
20		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:14:08:00:20:00:00:00
21		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:15:08:00:20:00:00:00
22		<input type="checkbox"/>	16	<input checked="" type="checkbox"/>	G_Port	1 Gb/s	<input type="checkbox"/>	20:16:00:E0:69:00:00:00


**Figure 21** Configure Ports dialog box (Open Systems management style)

- c. Click **10-100 km** or **RX BB Credit**, depending on which column you have displayed in your Configure Ports dialog box.

 **NOTE:** If a Switch supports BB credits by port, the 10-100 Km column is replaced by an RX BB Credit column.

- Click the **10-100 km** to enable extended distance buffering for a port. A check mark in the box indicates extended distance operation up to 100 kilometers (through repeaters) is enabled.
- Click the **RX BB Credit** to set minimum and maximum allowable port BB credit values. These values vary by Director. If an invalid value is entered, an Invalid RX BB Credit error message displays. The BB Credit value is validated as entered.

Click **Activate** and a RX-BB Credit Confirmation box displays. In addition to the maximum BB credit limit per port, the total BB credits allocated to all ports cannot exceed the buffer pool size.

 **NOTE:** Only 24-Port switches have a switch-wide buffer pool. The Configure Ports dialog box displays the total and available buffers at the bottom of the dialog box. When information is changed in the RX BB Credit column, this information also updates. If information is entered that exceeds the buffer pool and **Activate** is clicked, an error message displays. Also, ports for the 24-Port switches can be individually configured between 2–12, with a total number of port credits of 150.



Right-clicking in the RX-BB Credit column displays a RX BB Credits dialog box. For switches without buffer pools, this dialog box allows you to select **Set all**, which sets all ports to a single value or **Set all to maximum**, which set all ports to a maximum BB credit value. For switches with buffer pools, this dialog box allows you to select **Set all**, which sets all ports to a single value or to **Distribute**, which evenly distributes the pool buffers among all ports. Clicking **OK** changes the values in the Configure Port dialog box. Clicking **Activate** changes the values on the Switch.

- d. Click **LIN Alerts** to enable or disable LIN alerts for a port. A check mark in the box indicates alerts are enabled. When the feature is enabled and an incident occurs on the link, an alert indicator (yellow triangle) is displayed at the Hardware View, Port List View, and Port Card View pages, and a message is sent to configured e-mail recipients. LIN alerts are enabled by default.
- e. Click **Type** for a specified port and select generic port (**G\_Port**), fabric port (**F\_Port**), or expansion port (**E\_Port**) from the list box.
- f. Click **Speed** for a specified port. A Speed drop-down list is displayed. Select **1 Gb/s**, **2 Gb/s**, or **Negotiate** as the desired setting, depending on the speed capability of the device to be plugged into the port.

---

 **TIP:** A right-click in the Speed column allows you to select from a menu to set all ports to **1 Gb/s**, **2 Gb/s**, or **Negotiate**.

---


- g. Click a **Port Binding** check box to display a check mark and enable WWN binding for the selected port. This allows only a specific device to attach to the port. This device is specified by the WWN or nickname entered into the Bound WWN column. With the check box cleared, any device can attach to the port even if a WWN or nickname is specified in the Bound WWN column.  
or  
Enter a world wide name (WWN) in the Bound WWN field in the proper format (xx.xx.xx.xx.xx.xx.xx.xx) or a nickname configured through the Element Manager application. The device with this WWN or nickname will have exclusive attachment to the port if Port Binding is enabled. If a valid WWN or nickname is not entered in this field, but the Port Binding check box is checked (enabled), then no devices can connect to the port. If you enter a WWN or nickname in this field and do not place a check in the Port Binding check box, the WWN or nickname will be stored, and all devices can connect to the port.
2. Use the vertical scroll bar as necessary to display additional port information rows (up to 32 ports).
  3. Click **Activate** to save the configuration information and close the dialog box.

## Configure preferred ports

The preferred path feature lets you specify and configure one or more ISL data paths between multiple directors or switches in a fabric. Each participating director or switch must be configured as part of a desired path. The following rules apply when configuring a preferred path:

- The switch domain ID must be set to Insistent. For instructions, refer to [“Configure Switch Operating Parameters”](#) on page 42.
- Domain IDs range between 1 through 31.
- Source and exit port numbers are limited to the range of ports available on the director or switch (0 through 23).
- For each source port, only one path is defined to each destination domain ID.


---

 **NOTE:** Activating a preferred path can result in receipt of out-of-order frames if the preferred path differs from the current path, if input and output (I/O) is active from the source port, and if congestions is present on the current path.

---

To configure one or more preferred paths for the switch:

1. At the Hardware View, select **Configure > Preferred Path**. The Configure Preferred Paths dialog box is displayed ([Figure 22](#)).



**Figure 22** Configure Preferred Paths dialog box

2. Click **Add**. The Add Preferred Path dialog box is displayed ([Figure 23](#)).



**Figure 23** Add Preferred Path dialog box

3. At the Source Port field, enter a value between 0 through 23. For this switch, the value uniquely identifies the starting port for the preferred path.
4. At the Exit Port field, enter a value between 0 through 23. For this switch, the value uniquely identifies the exit port for the preferred path.
5. At the Destination Domain ID field, enter a value between 1 through 31. This value uniquely identifies the destination director or switch in the path.
6. Click **OK** to close the Add Preferred Path dialog box and add the path to the list at the Configure Preferred Paths dialog box.
7. Repeat [step 2](#) through [step 6](#) to configure additional preferred paths.
8. At the Configure Preferred Paths dialog box, click the **Enable Preferred Path** check box.
9. Click **Activate** to enable all configured preferred paths and close the dialog box.

## Configure ports (FICON management style)

If the switch is set to FICON management style, perform this procedure to enable extended distance operation and LIN alerts for Fibre Channel ports. Then, continue to ["Configure port addresses \(FICON\)"](#) on page 52 to define port names, configure ports as blocked or unblocked, and define the control unit port (CUP).

To configure switch ports:

1. At the Hardware View page for the selected switch, select **Configure > Ports**. The Configure Ports dialog box (FICON management style) is displayed ([Figure 24](#)).

Port #	10-100 km	LIN Alerts	Port Binding	Type	Speed	Bound WWN
0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:00:00:00:C9:00:00:00
1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:01:00:00:C9:00:00:00
2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:02:00:00:E0:69:00:00:00
3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:03:00:00:C9:00:00:00
4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:04:00:00:C9:00:00:00
5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:05:00:00:E0:69:00:00:00
6	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:06:00:00:E0:69:00:00:00
7	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:07:00:00:C9:00:00:00
8	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:08:00:00:C9:00:00:00
9	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:09:08:00:20:00:00:00
10	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:0A:00:60:48:00:00:00
11	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:0B:00:60:48:00:00:00
12	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:0C:00:00:C9:00:00:00
13	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:0D:00:60:48:00:00:00
14	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:0E:08:00:20:00:00:00
15	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:0F:08:00:20:00:00:00
16	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:10:00:E0:69:00:00:00
17	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:11:08:00:20:00:00:00
18	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:12:00:E0:69:00:00:00
19	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:13:00:E0:69:00:00:00
20	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:14:08:00:20:00:00:00
21	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	N/A	1 Gb/s	20:15:00:00:C9:00:00:00
22	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:16:00:E0:69:00:00:00
23	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	N/A	1 Gb/s	20:17:00:E0:69:00:00:00

**Figure 24** Configure Ports dialog box (FICON management style)

- a. Click **10-100 km** to enable extended distance buffering for a port. A check mark in the box indicates extended distance operation up to 100 kilometers (through repeaters) is enabled.
  - b. Click **LIN Alerts** to enable or disable LIN alerts for a port. A check mark in the box indicates alerts are enabled. When the feature is enabled and an incident occurs on the link, an alert indicator (yellow triangle) is displayed at the Hardware View, Port List View, and Port Card View pages, and a message is sent to configured e-mail recipients. LIN alerts are enabled by default.
  - c. Click the **WWN Binding** check box to display a check mark and enable WWN binding for the port. This allows only a specific device to attach to the port. This device is specified by the WWN or nickname entered into the Bound WWN column. With the check box cleared, any device can attach to the port even if a WWN or nickname is specified in the Bound WWN column.
  - d. Select a port speed in the Speed field.
  - e. Enter a World Wide Name (WWN) in the Bound WWN field in the proper format (xx . xx . xx . xx . xx . xx . xx . xx) or a nickname configured through the Element Manager application. The device with this WWN or nickname will have exclusive attachment to the port if WWN Binding is enabled. If a valid WWN or nickname is not entered in this field, but the WWN Binding check box is checked (enabled), then no devices can connect to the port. If you enter a WWN or nickname in this field and do not place a check in the WWN Binding check box, the WWN or nickname will be stored, and all devices can connect to the port.
2. Use the vertical scroll bar as necessary to display additional port information rows (up to 64 ports).
  3. Click **Activate** to save the configuration information and close the dialog box.

## Configure port addresses (FICON)

If the switch is set to FICON management style, configure port addresses to access the switch matrix and define Fibre Channel port names, configure ports as blocked or unblocked, and define the CUP name. For instructions on configuring port addresses, refer to the *HP StorageWorks Edge Switch Element Manager user guide*.

## Configure SNMP trap message recipients

Perform this procedure to configure community names, write authorizations, and network addresses for up to 12 SNMP trap message recipients per HAFM appliance or up to 6 SNMP trap message recipients per switch. A trap recipient is a management workstation that receives notification (through SNMP) if a switch event occurs.

To configure SNMP trap recipients:

1. At the Hardware View page for the selected switch, select **Configure > SNMP Agent**. The Configure SNMP Agent dialog box is displayed (Figure 25).

Community Name	Write Authorization	Trap Recipient	UDP Port Number
public	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		

**Figure 25** Configure SNMP Agent dialog box


- a. For each trap recipient to be configured, enter a community name of 64 or fewer alphanumeric characters in the associated Community Name field. The community name is incorporated in SNMP trap messages to ensure against unauthorized viewing or use.
  - b. Click the check box in the Write Authorization column to enable or disable write authorization for the trap recipient (default is disabled). A check mark in the box indicates write authorization is enabled. When the feature is enabled, a management workstation user can change the HAFM appliance's `sysContact`, `sysName`, and `sysLocation` SNMP variables.
  - c. Enter the IP address or DNS host name of the trap recipient (SNMP management workstation) in the associated Trap Recipient field. Use 32 or fewer alphanumeric characters. HP recommends using the IP address.
  - d. The default user datagram protocol (UDP) port number for trap recipients is 162. Enter a decimal port number in the associated UDP Port Number field to override the default.
2. To enable transmission of trap messages to configured SNMP management workstations, click **Enable Authorization Traps**. A check mark is displayed in the box when transmission is enabled.
  3. Click **Activate** to save the information and close the dialog box.

## Configure, enable, and test e-mail notification

Perform this procedure to configure, enable, and test e-mail and simple mail transfer protocol (SMTP) addresses to receive notification of switch (and other product) events. Configure and test procedures are performed at the HAFM appliance. E-mail notification is enabled for each switch at the HAFM application.

To configure, enable, and test e-mail server addresses:


1. Minimize the Hardware View and return to the HAFM application.
2. At the HAFM application or EWS main window, select **Monitor > Event Notification > Email**. The Email Event Notification Setup dialog box is displayed (Figure 26).

The image shows a dialog box titled "Email Event Notification Setup". At the top, there is a checkbox labeled "Enable Email Event Notification" which is currently unchecked. Below this, there are several input fields: "E-mail Server" (empty), "Reply Address" (containing "unknown@unknown.com"), and "Summary Interval" (set to "0" with a dropdown menu showing "minutes"). Under "E-mail Test Options", there are two radio buttons: "Send to" (selected) and "Send to all users enabled for notification". The "Send to" option has a text field next to it containing "unknown@unknown.com". Below the radio buttons is a button labeled "Send Test E-mail". At the bottom left is a button labeled "User List...". At the bottom right are three buttons: "OK", "Cancel", and "Help".

**Figure 26** Configure Email dialog box


3. Enter the IP address or DNS host name of the SMTP server in the E-mail Server field. Use 64 or fewer alphanumeric characters. HP recommends using the IP address.
4. Enter the e-mail address to which e-mail replies should be sent in the Reply Address field.
5. At the Summary Interval field, enter the length of time the application should wait between notifications. Select seconds, minutes, or hours from the associated drop-down list.

6. To specify users that are to receive e-mail notification, click **User List**. The HAFM 8.6 Server Users dialog box is displayed, as shown in Figure 27.



**Figure 27** HAFM 8.6 Server Users dialog box

7. To enable e-mail notification for a user, select the check box in the Email column. An unchecked box indicates e-mail notification is not enabled.
8. To configure event types for which e-mail notification is sent, select the Filter link adjacent to the check box. The Define Filter dialog box is displayed.




**Figure 28** Define Filter dialog box

9. Select the filters that you want for this user.
10. Click **OK** to close the Define Filter dialog box.
11. Click **OK** to close the HAFM 8 Server Users dialog box.
12. Click **Test Email**. A test message is sent to configured e-mail recipients.
13. Click **OK** to save the information and close the Email Event Notification Setup dialog box.
14. Maximize the Hardware View (Element Manager).

15. At the Hardware View, select **Maintenance > Enable E-Mail Notification**. A check mark is displayed in the check box to indicate e-mail notification for the switch is enabled, and the menu closes.

---

 **NOTE:** Using HAFM, enable or disable e-mail event notification for each switch individually.

---


## Configure and enable call-home features

There are two call-home features available, and only one is installed when the HAFM application is installed on the HAFM appliance. To learn more about configuring call-home features, refer to the *HP StorageWorks HA-Fabric Manager Appliance installation guide*.

## Configure and enable ethernet events

Perform this procedure to configure and enable Ethernet events. An Ethernet event is recorded (after a user-specified time interval) when the switch-to-HAFM appliance communication link drops. To configure and enable Ethernet events:

1. Minimize the Hardware View and return to the HAFM application.
2. At the HAFM or EWS main window, select the **Monitor > Ethernet Event**. The Configure Ethernet Events dialog box is displayed (Figure 29).



**Figure 29** Configure Ethernet Events dialog box


3. Click the **Enable Ethernet Events** check box. A check mark is displayed in the check box to indicate Ethernet events are enabled.
4. Enter a value from 10 through 120 minutes in the Ethernet Timeout field.
5. Click **OK** to close the dialog box.



## Configure, enable, and test call home event notification

Telephone numbers and other information for the call-home feature are configured through the Windows 2000 dial-up networking application. Refer to "[Configure and enable call-home features](#)" on page 56 for configuration information. To configure, enable, and test call-home event notification:

1. Minimize the Hardware View and return to the HAFM application.
2. At the HAFM or EWS main window, select the **Event Notification** and **Call Home** options from the Monitor menu. The Call Home Event Notification Setup dialog box is displayed ([Figure 30](#)).



**Figure 30** Call Home Event Notification Setup dialog box

3. Click the **Enable Call Home Event Notification** check box. A check mark is displayed in the check box to indicate call-home event notification is enabled.



**NOTE:** The enable function must also be activated for each switch through the Element Manager application. Call-home event notification can be active for some switches and inactive for others.

4. Click **Send Test**. A call-home test message is sent.
5. Click **OK** to close the dialog box.
6. Maximize the Hardware View page.
7. At the Hardware View, select **Enable Call Home Notification** from the Maintenance menu. A check mark appears in the check box to indicate call-home event notification for the switch is enabled, and the menu closes.

## Configure threshold alerts

A threshold alert notifies users when the transmit (Tx) or receive (Rx) throughput reaches specified values for specific switch ports or port types, (E\_Ports or F\_Ports).

You are notified of a threshold alert in four ways:

- A yellow triangle that is displayed on the port in the Port Card View.
- A yellow triangle that is displayed on the port in the Hardware View.
- A yellow triangle that is displayed in the Alert column of the Port List View.
- A yellow triangle that is displayed by the Threshold Alerts field in the Port Properties dialog box.
- Detailed threshold alert data recorded in the Threshold Alert Log.

Use the Threshold Alerts option on the Configure menu to configure the following:

- Name for the alert.
- Enter of threshold for the alert (Rx, Tx, or either).
- Active or inactive state of the alert.
- Threshold criteria:
  - Percent traffic capacity utilized—The percent of the port's throughput capacity achieved by the measured throughput. This setting constitutes the threshold value. For example a value of 50 means that the port's threshold is reached when throughput is 50% of capacity.
  - Time interval during which throughput is measured and alert notification can occur.
  - The maximum cumulative time that the throughput percentage threshold can be exceeded during the set time interval before an alert is generated.
- Ports for which you are configuring threshold alerts.


You can configure up to 16 alerts, and any number of alerts can be active at one time. Use the following procedures to create a new threshold alert, or to modify, activate, deactivate, or delete an alert.

### Create new alerts

1. At the Hardware View page, select **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed, as shown in [Figure 31](#).




**NOTE:** If alerts are configured, they will display in table format showing the name of the alert, type of alert (Rx, Tx, or Rx or Tx), and alert state (inactive or active).



**Figure 31** Configure Threshold Alerts dialog box

2. Click **New**. The New Threshold Alert dialog box is displayed, as shown in [Figure 32](#).




**Figure 32** New Threshold Alerts dialog box—first screen

3. Enter a name from one to 64 characters in length in the Threshold Alert Name field. All characters in the ISO Latin-1 character set, excluding control characters, are allowed.
4. Select one of the following from the Threshold Type drop-down list:
  - **Transmit**—An alert will occur if the threshold set for transmit throughput is reached.
  - **Receive**—An alert will occur if the threshold set for receive throughput is reached
  - **Receive and Transmit**—An alert will occur if the threshold set for either receive or transmit throughput is reached.
5. Click **Next**. A new screen is displayed with additional parameters, as shown in [Figure 33](#). The name configured for the alert appears at the top of the screen.



**NOTE:** Click **Previous** if you need to return to the previous screen.



**Figure 33** New Threshold Alerts dialog box—second screen

6. Enter a percentage from 1 through 100 for % utilization. When throughput reaches this percentage of port capacity, a threshold alert will occur.
7. Enter the amount of cumulative minutes in which the % utilization should exist during the notification interval before an alert is generated. You can also select **At any time** if you want an alert to occur whenever the set % utilization is reached. The valid range is from 1 to the interval value set in [step 8](#).
8. Enter the interval in minutes in which throughput is measured and threshold notifications can occur. The valid range is 5 minutes to 70,560 minutes.
9. Click **Next**. A new screen is displayed for selecting ports for the alerts, as shown in [Figure 34](#).

Select port(s) to run threshold alert on:

☐ Port Type

☐ E\_Ports

☐ F\_Ports

☒ Port List

☒ Port 0

☒ Port 1

☒ Port 2

☒ Port 3

☒ Port 4

☒ Port 5


☒ Port 6

**Figure 34** New Threshold Alerts dialog box—third screen

**10.** Select either **Port Type** or **Port List**.


- For Port Type, select either **E\_Ports** or **F\_Ports** to cause this alert to generate for all ports configured as E\_Ports or F\_Ports respectively.
- For Port List, you can select individual ports by clicking the check box by each port number or set all ports. Selecting **Set All Ports** places a check mark by each port number. Selecting **Clear All Ports** clears the check marks by each port number.

11. Click **Next**. A final screen is displayed to provide a summary of your alert configuration, as shown in [Figure 35](#).



**Figure 35** New Threshold Alerts dialog box—summary screen

12. Click **Finish**. The Configure Threshold Alerts dialog box is displayed with a list of the name, type, and state of the alert that you just configured.
13. At this point, the alert is not active. To activate the alert, select the alert information that appears in the Configure Threshold Alerts table and click **Activate** as shown in [Figure 36](#). The alert is activated.



**Figure 36** Configure Threshold Alerts dialog box—alert activated

## Modify alerts

Use the following steps to modify an existing threshold alert configuration:

1. At the Hardware View page, select **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed.  
Select the alert that you want to modify by clicking the alert information in the table. If the alert is active, an error message is displayed prompting you to deactivate the alert.
2. If the alert is active, click **Deactivate**, then select the alert information in the table again.
3. Click **Modify**. An initial Modify Threshold screen that allows the you to change the threshold type is displayed.
4. Select a threshold type from the drop-down list.
5. Click **Next** when you are done. A Modify Threshold screen is displayed. This screen allows you to change the % utilization, cumulative minutes for the threshold to occur before notification, and the time interval for measuring throughput and for alert notification.
6. Make appropriate changes, then continue through the Modify Threshold screens, making changes as necessary, until the summary screen is displayed in the alert configuration.
7. Perform either of the following steps:
  - If you need to change any parameters, click **Previous** or **Next** to display the desired Modify Threshold screen.
  - Click **Finish** when you are done.

## Activate or deactivate alerts

Use the following steps to activate or deactivate existing threshold alerts. In the active state, notifications are generated for the alert. In the inactive state, notifications do not occur.

1. At the Hardware View page, select **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed.  
The port's current state, inactive or active, is listed in the State column.
2. To change the state, select the alert by the alert information in the table.
3. If the alert is active, select **Deactivate** to change to the inactive state. If the alert is inactive, select **Activate** to change to the active state.


## Delete alerts

Use the following steps to delete existing threshold alerts:

1. At the Hardware View page, select **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed.
2. Select the alert that you want to delete by selecting the alert information in the table and click **Delete**. A message is displayed asking you to confirm the deletion.
3. Click **Yes**. The alert is removed from the dialog box.


## Configure SANtegrity authentication

Use this optional feature to configure authentication security settings. You configure these setting using the SANtegrity Authentication dialog box.

 **NOTE:** You must have Administrator privileges to access the SANtegrity Authentication dialog box.

To access the SANtegrity Authentication dialog box:

From the Element Manager window, select **Configure > SANtegrity Authentication**. The SANtegrity Authentication dialog box is displayed ([Figure 37](#)).



**Figure 37** SANtegrity Authorization dialog box

This dialog box contains five tabs:

- **Users**—Allows you to setup users who access the switch from CLI and Web interfaces.
- **Software**—Allows you to setup software applications that communicate with the switch through API, as well as OSMS authentication.
- **Devices**—Allows you to set device-to-device authentication parameters. The Devices tab is preferred path PFE key enabled. If a proper PFE key is not provided, the Devices tab is not accessible. See "[Configure feature key](#)" on page 64 for more information.
- **IP Access Control**—Allows you to setup IP addresses that can manage the switch.
- **Radius Servers**—Allows you to set Radius server parameters that the switch uses to communicate the authentication information to the designated Radius servers.

For information about using each of these tabs, see the online Help.

## Back up HAFM configuration data

It is important to back up the HAFM configuration data. This data is used to restore the HAFM appliance operating environment in case of hard drive failure. Refer to the *HP StorageWorks HA-Fabric Manager appliance installation guide* for instructions on backing up the HAFM configuration data.

Once the HAFM configuration data is backed up, go to [“Connect cables to Fibre Channel ports”](#) on page 65.

## Configure Open Systems management appliance

For complete procedures on configuring this optional feature, refer to *HP StorageWorks Edge Switch Element Manager user guide*.

## Configure FICON management appliance

For complete procedures on configuring this optional feature, refer to *HP StorageWorks Edge Switch Element Manager user guide*.

## Configure feature key

For complete procedures on configuring this feature, refer to *HP StorageWorks Edge Switch Element Manager user guide*.

## Configure Open Trunking

This option is only available if the optional Open Trunking feature is installed. Selecting this option opens the Configure Open Trunking dialog box. For details on enabling Open Trunking and configuring such parameters as congestion thresholds for ports, event notification options, and low BB credit threshold, refer to the *HP StorageWorks Edge Switch Element Manager user guide*.

## Enable Embedded Web Server

Use the following steps to enable EWS:

1. At the Hardware View page, select **Configure > Enable Web Server**. Selecting Enable Web Server automatically places a check mark in the check box.
2. Select **Enable Web Server** again to remove the check mark and disable the EWS interface. When disabled, remote users cannot access the interface.

For complete information on using the EWS, see [“Using the Embedded Web Server”](#) on page 71.

## Enable Telnet

Use the following steps to enable Telnet:

1. At the Hardware View, select **Configure > Enable Telnet**. Selecting Enable Telnet automatically places a check mark in the check box.
2. Select **Enable Telnet** again to remove the check mark and disable Telnet access. When disabled, remote users cannot access the switch through Telnet.



## Connect cables to Fibre Channel ports

Perform this task to connect devices to the switch. To cable Fibre Channel ports:

1. Route single mode or multimode fiber-optic cables (depending on the type of SFP pluggable optic transceivers installed) from the desired devices to ports at the front of the switch.
2. Connect device cables to small form factor pluggable (SFP) transceivers.
3. Perform one of the following:
  - a. If the switch is installed on a table or desk top, bundle and secure the Fibre Channel cables as directed by the customer.
  - b. If the switch is installed in an HP-supplied equipment rack, bundle Fibre Channel cables from the switch and other equipment (groups of 16 maximum), and secure them as directed by the customer.
4. Set the switch online.

## Connect the switch to a Fabric

To provide Fibre Channel connectivity between public devices and fabric-attached devices, connect the switch to an expansion port (E\_Port) of an HP director or switch. The switch port to switch port connection is called an interswitch link (ISL). To fabric-attach the switch and create an ISL:

1. Ensure that the switch is defined to the HAFM application or defined to the HAFM appliance (defined while performing ["Enabling HAFM to manage the switch"](#) on page 35).
2. Ensure that the preferred domain ID for the switch is unique and does not conflict with the ID of another switch or director participating in the fabric. To change the domain ID, see ["Configure Switch Operating Parameters"](#) on page 42.
  - If the domain ID must be changed from the HAFM interface, see ["Configure Switch Operating Parameters"](#) on page 42.
  - If the domain ID must be changed from the Element manager, see ["Configure switch and fabric parameters"](#) on page 76.
3. Ensure that the R\_A\_TOV and E\_D\_TOV values for the switch are identical to the values for all switches participating in the fabric. To change the values, see ["Configure fabric operating parameters"](#) on page 44.
4. Route a multimode or single mode fiber-optic cable (depending on the type of SFP transceiver installed) from a customer-specified E\_Port of the switch to the switch.
5. Connect the switch-attached fiber-optic cable to the port SFP transceiver.
6. If the switch is managed by an attached HAFM appliance, go to [step 7](#). If the switch is managed by the Embedded Web Server interface:
  - a. Select **View** at the left side of the window. The View window opens with the Switch tab selected and displayed.
  - b. At the View window, click the Port Properties tab. The Port Properties page is displayed with 0 selected, and port information listed for port 0.

- c. Select the port number of the port used to make this ISL connection.
  - d. Ensure that the Operational State field displays *Online* and the Reason field displays *N/A* or is blank. If an ISL segmentation or other problem is indicated, refer to the *HP StorageWorks Edge Switch 2/32 service manual* to isolate the problem. If no problems are indicated, installation tasks are complete.
7. At the HAFM appliance's Product View page, double-click the switch icon. The Hardware View page for the selected switch is displayed.
  8. Double-click the port connector used to make this ISL connection to open the Port Properties dialog box (Figure 38).


Port Number	0
Port Name	
Type	F_Port
Operating Speed	2 Gb
Fibre Channel Address	
Port WWN	McDATA-20:04:0B:00:88:A0:54:56
Attached Port WWN	Not logged in
Block Configuration	Unblocked
10-100 ien Configuration	Off
LIN Alerts Configuration	On
Beaconing	Off
Link Incident	None
Operational State	No Light
Reason	
Threshold Alert	

Close Help

**Figure 38** Port Properties dialog box

9. Ensure that the Link Incident field displays *None* and the Reason field is blank. If an ISL segmentation or other problem is indicated, refer to the *HP StorageWorks Edge Switch 2/32 service manual* to isolate the problem. If no problems are indicated, installation tasks are complete.

---

 **NOTE:** If the Open Trunking feature is installed, an additional field (Congested Threshold %) is displayed in the Port Properties dialog box. This field displays the active congested threshold percentage currently configured in the Configure Open Trunking dialog box.

---

## Unpack, inspect, and install the Ethernet hub (optional)

The HAFM appliance and one or more switches connect through an Ethernet hub installed on a 10/100 Mbps LAN segment. One hub port is required to connect the HAFM appliance, and one hub port is required to connect each switch. A combination of up to 48 HP switches can be configured and managed by a single HAFM appliance, therefore multiple hubs may be required to provide sufficient port connections. These hubs must be connected in accordance with the hub manufacturer's specifications. HP recommends using a star or hub-and-spoke topology when connecting multiple hubs. The HAFM appliance must be connected to the center hub, and there should never be more than two hubs between the HAFM appliance and any switch. Refer to the hub manufacturer's documentation for more detailed information.

For instructions to unpack and inspect one or more Ethernet hubs, and install the hubs in a desktop or rack-mount configuration, refer to the appropriate Ethernet hub documentation.


## Using HAFM from a remote location

Use this section to install the HAFM client on a remote workstation.

### Remote workstation minimum requirements

The following minimum requirements must be met in order to install HAFM on a remote workstation.

---

 **NOTE:** In order for HAFM to function properly, compatible versions must be installed on both the client machines and the HAFM appliance.

---


- Desktop or notebook PC with color monitor, keyboard, and mouse, using an Intel® III processor with a 700 MHz or greater clock speed, and using the Microsoft Windows 95, Windows 2000 (with Service Pack 4), Windows XP, Windows NT 4.0 (with Service Pack 6a), or Windows Server 2003.
- UNIX® workstation with color monitor, keyboard, and mouse, using a:
  - Linux® based system using an Intel Pentium III processor with 1 GHZ or greater clock speed, using Red Hat 7.3 or higher operating system.
  - Hewlett-Packard HA PA-RISC processor with a 400 MHz or greater clock speed, using the HP-UX 11 or higher operating system.
  - Sun Microsystems UltraSPARC II processor with a 400 MHz or greater clock speed, using the SunOS Version 7 or higher operating system.
  - IBM Power3-II microprocessor with a 333 MHz or greater clock speed, using the AIX Version 4.3.3 or higher operating system.
  - Linux based system using an Intel Pentium III processor with 1 GHZ or greater clock speed, using Red Hat 7.3 or higher operating system.
- At least 15 MB available on the internal hard drive.
- 32 MB or greater RAM.
- Video card supporting 256 colors at 800 x 600 pixel resolution.

- Ethernet network adapter.
- Java-enabled Internet browser, such as Microsoft Internet Explorer (Version 4.0 or later) or Netscape Navigator (Version 4.0 or later).

## Install HAFM client on a remote workstation

Use these steps to install HAFM on a remote client:

1. Verify that the workstation and the Ethernet LAN segment (with the Edge Switch 2/32 attached) are connected through the Internet.
2. At the workstation, launch the browser application.
3. At the browser, enter the HAFM appliance IP address.
4. The HAFM splash screen is displayed with the following options, see [Figure 39](#).
  - a. Install HAFM remote client application—Select this option to install the application for your workstation platform.
  - b. Download SNMP MIB files—The Management Information Base (MIB) files are provided in standard ASN.1 syntax and may be installed into the MIB database of any SNMPv2 compliant Network Management Station.



**Figure 39** HAFM remote client install

5. To install the remote client application, scroll down to the information that pertains to your platform, and follow the instructions provided.
6. After you have downloaded the installer executable, the InstallAnywhere Wizard is displayed. Follow the instructions provided to continue the installation.

## Launch HAFM from the remote client

Use these steps to launch HAFM from a remote client:

1. Double-click the **HAFM** icon to launch HAFM. The HAFM Login screen is displayed.
2. Enter the user name and password.



**NOTE:** The default user name is *Administrator*. The default password is *password*. Both user name and password are case-sensitive.

---

3. Enter the IP address of the HAFM appliance, or select an HAFM appliance from the HAFM appliance drop-down list, if they have been logged in to previously.
4. Click **Login**. The HAFM application opens.




---

## 3 Using the Embedded Web Server

If an HAFM appliance is not available, or is not used to manage this edge switch, you can use the Embedded Web Server (EWS) interface to configure the Edge Switch 2/32. Selectively perform the following configuration tasks according to the customer's installation requirements:

- [Configure switch ports](#), page 73
- [Configure switch identification](#), page 74
- [Configure date and time](#), page 75
- [Configure switch and fabric parameters](#), page 76
- [Configure network information](#), page 79
- [Configure SNMP trap message recipients](#), page 80
- [Configure user rights](#), page 82
- [Reset configuration data](#), page 83

---


 **NOTE:** This chapter describes the initial set up of the Edge Switch 2/32 using the EWS interface. For additional information on configuring more advanced features using EWS, see the online EWS help or the *HP StorageWorks Embedded Web Server user guide*.

---

### Launch EWS

Use the following steps to launch EWS.


---

 **NOTE:** Internet access and a standard Web browser is required. HP recommends Netscape Navigator 4.6 or higher, or Microsoft Internet Explorer 4.0 or higher.

---

1. Ensure that the browser-capable PC and the Ethernet LAN segment (with the switch attached) are connected.
2. At the PC, launch the browser application (Netscape Navigator or Internet Explorer).


3. At the browser, enter the IP address of the switch as the internet uniform resource locator (URL). Use the default IP address of 10.1.1.10, the factory preset of 10.1.1.10, or the IP address configured while performing "Configure network information" on page 79. The Enter Network Password dialog box is displayed (Figure 40).



**Figure 40** Enter Network Password dialog box


4. Enter the default user name and password.

---

 **NOTE:** The default user name is *Administrator* and the default password is *password*. The user name and password are case-sensitive.

---

5. Click **OK**. The Embedded Web Server interface opens with the View window displayed (Figure 41).



**Figure 41** Embedded Web Server interface—View window




# Configure switch ports

Perform the procedure in this section to configure names and operating characteristics for the switch ports.

To configure switch Fibre Channel ports:

1. At the Switch View, select **Configure > Ports**. The Configure Ports tab is displayed (Figure 42).



**Figure 42** Configure Ports tab

- a. For each port to be configured, enter a port name of 24 or fewer alphanumeric characters in the associated Name field. The port name should identify the device to which the port is attached.
- b. Click the check box in the **Blocked** column to block or unblock a port (default is unblocked). A check mark in the box indicates the port is blocked. Blocking a port prevents the attached device from communicating with the switch. A blocked port continuously transmits the offline sequence (OLS).
- c. Click the check box in the **FAN** column to enable or disable the fabric address notification (FAN) feature (default is enabled). A check mark in the box indicates FAN is enabled. When the feature is enabled, the port transmits a FAN frame after loop initialization to verify that FC-AL devices are still logged in. HP recommends enabling this option for ports configured for loop operation.
- d. Click the port type from the Type drop-down list. Available selections are:
  - Generic mixed port (**GX\_Port**)—Use this selection to configure a port as a generic loop port (GL\_Port). This selection is available only if enabled through an optional feature key.
  - Fabric mixed port (**FX\_Port**)—Use this selection to configure a port as a fabric loop port (FL\_Port).
  - Generic port (**G\_Port**)—This selection is available only if enabled through an optional feature key.

- Fabric port (**F\_Port**).
  - Expansion port (**E\_Port**)—This selection is available only if enabled through an optional feature key.
2. Select from the drop-down list in the Speed column to configure the port transmission rate. Available selections are:
    - **Negotiate**—Auto-negotiate between 1.0625 and 2.125 gigabit per second (Gbps) operation. This is the default selection.
    - **1 Gb/sec**—1.0625 Gbps operation.
    - **2 Gb/sec**—2.125 Gbps operation.
  3. Click **Activate** to save the information and close the Configure Ports dialog box.

## Configure switch identification

Perform this procedure to configure the switch name, description, location, and contact person. The Name, Location, and Contact variables configured here correspond respectively to the SNMP variables `sysName`, `sysLocation`, and `sysContact`. These variables are used by SNMP management workstations when obtaining data from managed switches.

To configure the switch identification:

1. At the Configure window, click the **Switch** tab. The Switch page is displayed with the Identification tab selected (Figure 43).

**Figure 43** Switch page—Identification tab


- a. Enter a switch name of 24 or fewer alphanumeric characters in the Name field. Each switch should be configured with a unique name.  
If the switch is installed on a public LAN, the name should reflect the switch's Ethernet network DNS host name. For example, if the DNS host name is `hpes232.hp.com`, then enter **hpes232**.

- b. Enter a switch description of 255 or fewer alphanumeric characters in the Description field.
  - c. Enter the switch physical location (255 or fewer alphanumeric characters) in the Location field.
  - d. Enter the name of a contact person (255 or fewer alphanumeric characters) in the Contact field.
2. Click **Activate** to save the information. The message Your changes to the identification configuration have been successfully activated is displayed.

## Configure date and time

Perform this procedure to configure the effective date and time for the switch. To set the date and time:

1. At the Configure window, click the **Switch** tab, then select the **Date/Time** tab. The Switch page is displayed with Date/Time tab selected (highlighted red) (Figure 44).



**Figure 44** Switch page—Date/Time tab

- a. Click the Date fields that require change, and enter numbers in the following ranges:  
 Month (MM): 1 through 12  
 Day (DD): 1 through 31  
 Year (YY): greater than 1980
  - b. Click the Time fields that require change, and enter numbers in the following ranges:  
 Hour (HH): 0 through 23  
 Minute (MM): 0 through 59  
 Second (SS): 0 through 59
2. Click **Activate** to save the information. The message Your changes to the date/time configuration have been successfully activated is displayed.


## Configure switch and fabric parameters

Perform this procedure to configure the following switch and fabric operating parameters: Buffer-to-Buffer Credit (BB\_Credit), Error Detect Time Out Value (E\_D\_TOV), and Resource Allocation Time Out Value (R\_A\_TOV), preferred domain ID and switch priority.

### Configure switch parameters

The switch must be set offline to configure switch operating parameters. To configure the parameters:


1. Set the switch offline as follows:
  - a. At the View window, select **Operations** at the left side of the panel. The Operations panel opens with the Switch Beacon page displayed.
  - b. At the Current State window, click **Set Offline**. The message `Your operations changes have been successfully activated` is displayed.
2. At the View window, select **Configure** at the left side of the panel. The Configure panel opens with the Ports page displayed.
3. At the Configure panel, click the **Switch** tab, then select the **Parameters** tab. The Switch page is displayed with Switch Parameters shown (Figure 45).



**Figure 45** Switch page—Parameters tab

4. Set the switch parameters:
  - a. In the Preferred Domain ID field, enter a value from 1 through 31 (default is 1). The domain ID uniquely identifies each switch in a fabric.

---

 **NOTE:** All fabric-attached switches must have unique domain IDs. If the value is not unique, the E\_Port connection to the switch segments and the switch cannot communicate with the fabric.

---

- b. Select **Enabled** or **Disabled** from the Insistent Domain drop-down list. The default state is disabled. This option is not supported unless the SANtegrity feature is installed.
- If insistent domain is enabled, the domain ID configured in the Preferred Domain ID field will become the active domain identification when the fabric initializes.

Notes:


- This option is required if High Availability Fabric Manager (HAFM) is enabled.
  - If you enable Insistent Domain while the switch or director is online, the Preferred Domain ID will change to the current active domain ID if the IDs are different.
- c. Select **Enabled** or **Disabled** from the Rerouting Delay drop-down list. The default state is enabled.
- If rerouting delay is enabled, traffic is delayed through a fabric by the specified E\_D\_TOV time. This delay ensures Fibre Channel frames are delivered to their destination in order, even if a change to the fabric topology creates a new (shorter) transmission path.
- d. Select **Enabled** or **Disabled** from the Domain RSCNs drop-down list. The default state is disabled.
- Domain register for state change notifications (domain RSCNs) are sent between end devices in a fabric to provide additional connection information to host bus adapters (HBAs) and storage devices. As an example, this information might be that a logical path has been broken because of a physical event, such as a fiber optic cable being disconnected from a port. Consult with your HBA and storage device vendor to determine if enabling Domain RSCNs will cause problems with your HBA or storage products.
- e. Select **Enabled** or **Disabled** from the Suppress RSCNs on Zone set activations drop-down list. The default state is disabled.
- When the parameter is enabled, attached devices do not receive notification following any change to the fabric's active zone set.
- When the parameter is disabled, attached devices (registered through the fabric format domain register) do receive notification following any change to the fabric's active zone set.
5. Click **Activate** to save the information. The message `Your changes to the operating parameters configuration have been successfully activated` is displayed.

## Set fabric parameters

The switch must be set offline to configure fabric parameters. To configure the parameters:

1. Set the switch offline as follows:
  - a. At the View window, select **Operations** at the left side of the panel. The Operations panel opens with the Switch Beacon page displayed.
  - b. At the Current State window, click **Set Offline**. The message `Your operations changes have been successfully activated` is displayed.
2. At the View window, select **Configure** at the left side of the panel. The Configure panel opens with the Ports page displayed.

3. At the Configure panel, click the **Switch** tab, then select **Fabric Parameters**. The Switch page is displayed with the Fabric Parameters options (Figure 46).



**Figure 46** Switch page—Fabric Parameters tab

4. Set the fabric parameters:
  - a. At the BB\_Credit field, enter a value from 1 through 60 (buffers). The default is 16. Use a value of 60 (buffers) only for extended distance port operation.
  - b. At the R\_A\_TOV field, enter a value from 10 through 1200 tenths of a second (one through 120 seconds). The default is 10 seconds (100 tenths).

All fabric-attached switches must be set to the same R\_A\_TOV. If the value is not compatible, the E\_Port connection to the switch segments and the switch cannot communicate with the fabric. In addition, the R\_A\_TOV must be greater than the E\_D\_TOV.
  - c. At the E\_D\_TOV field, enter a value from 2 through 600 tenths of a second (0.2 through 60 seconds). The default is 20 tenths of a second (2 seconds).

All fabric-attached switches must be set to the same E\_D\_TOV. If the value is not compatible, the E\_Port connection to the switch segments and the switch cannot communicate with the fabric. In addition, the E\_D\_TOV must be less than the R\_A\_TOV.
  - d. The switch priority value designates the fabric's principal switch. The principal switch controls the allocation and distribution of domain IDs for all fabric directors and switches (including itself). At the Switch Priority field, select **Principal**, **Never Principal**, or **Default** (the default setting is Default).
  - e. Select the Interop mode:
    - **McData Fabric 1.0.** (default). Select this mode if the fabric contains only M-Series switches and switches that are operating in McData Fabric 1.0 mode.
    - **Open Fabric 1.0.** Select this mode if the fabric contains HP directors and switches, as well as other open-fabric compliant switches. Select this mode for managing heterogeneous fabrics.
5. Click **Activate** to save the information. The message Your changes to the operating parameters configuration have been successfully activated is displayed.

6. Set the switch online:
  - a. At the View window, select **Operations** at the left side of the panel. The Operations panel opens with the Switch Beacon page displayed.
  - b. At the Operations panel, click the **Online State** tab, then click **Set Online**. The message Your operations changes have been successfully activated is displayed.

## Configure network information


Verify that the type of LAN installation with the customer's network administrator. If one switch is installed on a dedicated LAN, network information (IP address, subnet mask, and gateway address) does not require change. Go to "[Configure switch ports](#)" on page 73.

If multiple switches are installed, or a public LAN segment is used, network information must be changed to conform to the customer's LAN addressing scheme. Perform one of the following:

- If network information was changed while performing "[Configure switch network information](#)" on page 30, this procedure is not required. Go to "[Configure SNMP trap message recipients](#)" on page 80.
- If network information was not changed, perform this procedure.

Perform the following steps to change a switch IP address, subnet mask, or gateway address.

1. Click **Configure** at the left side of the window. The Configure window opens with the Ports page displayed.
2. At the Configure window, click the **Switch** tab, then click the **Network** tab. The Switch page is displayed with the Network tab selected ([Figure 47](#)).



**Figure 47** Switch page—Network tab

- a. At the IP Address field, enter the new value as specified by the customer's network administrator (default is 10.1.1.10, factory preset is 10.1.1.10).
- b. At the Subnet Mask field, enter the new value as specified by the customer's network administrator (default is 255.0.0.0).
- c. At the Gateway Address field, enter the new value as specified by the customer's network administrator (default is 0.0.0.0).

3. Click **Activate** to save the information. The following message box is displayed (Figure 48).

Your changes to the Network configuration have been successfully activated. The following Network information has been configured to the switch:

IP Address:	10.1.1.11
Subnet Mask:	0.0.0.0
Gateway Address:	255.0.0.0

In order to re-establish your browser management connection, you must update local ARP tables on your operating system and direct your web browser to the new IP Address displayed above. Please consult the Installation and Service Manual provided with this product for more information.

**Figure 48** Network configuration changes activated

4. Update the address resolution protocol (ARP) table for the browser PC.
  - a. Select **File > Exit** to close the Embedded Web Server and browser applications. The Windows desktop is displayed.
  - b. Select **Start > Programs > Command Prompt**. A disk operating system (DOS) window is displayed.
  - c. Delete the switch's *old* IP address from the ARP table. At the command (C:\) prompt, enter `arp -d xxx.xxx.xxx.xxx`, where `xxx.xxx.xxx.xxx` is the old IP address for the switch.
  - d. Click close (X) at the upper right corner of the DOS window to close the window and return to the Windows desktop.
5. At the PC, launch the browser application (Netscape Navigator or Internet Explorer).
6. At the browser, enter the switch's *new* IP address as the Internet URL. The Username and Password Required dialog box is displayed.
7. Enter the default user name and password.



**NOTE:** The default user name is *Administrator* and the default password is *password*. The user name and password are case-sensitive.

8. Click **OK**. The Embedded Web Server interface opens with the View window displayed.

## Configure SNMP trap message recipients

Perform this procedure to configure community names, write authorizations, and network addresses for up to 6 SNMP trap message recipients per switch and up to 12 SNMP trap message recipients per HAFM appliance. A trap recipient is a management workstation that receives notification (through SNMP) if a switch event occurs.

To configure SNMP trap recipients:

1. Click **Configure** at the left side of the window. The Configure window opens with the Ports tab displayed.



2. At the Configure window, click the **Management** tab. The Management page is displayed with SNMP tab selected (Figure 49).

Configure: Refresh-5/28/03 at 10:35:19

Ports Switch **Management** Zoning Security Performance

SNMP CLI GSM/S

☒ Enable SNMP Agent FA MIB Version: F4MIB3.1  
☐ Enable Authentication Traps

Community Name	Write Authorization	Trap Recipient	UDP Port Number
public	<input checked="" type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		

Activate Cancel


**Figure 49** Management page—SNMP tab

- a. For each trap recipient to be configured, enter a community name of 32 or fewer alphanumeric characters in the associated Community Name field. The community name is incorporated in SNMP trap messages to ensure against unauthorized viewing or use.
  - b. Click the check box in the **Write Authorization** column to enable or disable write authorization for the trap recipient (default is disabled). A check mark in the box indicates write authorization is enabled. When the feature is enabled, a management workstation user can change `sysContact`, `sysName`, and `sysLocation` SNMP variables.
  - c. Enter the IP address or DNS host name of the trap recipient (SNMP management workstation) in the associated Trap Recipient field. Use 64 or fewer alphanumeric characters. HP recommends using the IP address.
  - d. The default user datagram protocol (UDP) port number for trap recipients is 162. To override this port number; click the **Advanced** option. The dialog box expands to show a UDP Port Number column. Enter a decimal port number in the associated UDP Port Number field to override the default.
3. Click **Activate** to save the information. The message Your changes to the SNMP configuration have been successfully activated is displayed.

## Enable or disable the CLI

Perform this procedure to toggle (enable or disable) the state of the switch's command line interface. To change the CLI state:

1. At the Configure window, click the **CLI** tab. The Management page is displayed with the CLI tab selected, as shown in [Figure 50](#).




**Figure 50** Management page—CLI tab

2. Perform one of the following steps as required:
  - Click **Enable** to activate the CLI. The message Your changes to the CLI enable state have been successfully activated is displayed.
  - Click **Disable** to deactivate the CLI. The message Your changes to the CLI disable state have been successfully activated is displayed.

## Configure user rights

Perform this procedure to change the administrator-level and operator-level passwords used to access the EWS interface through the Enter Network Password dialog box.

---

 **NOTE:** If you want to create a user account, review the *Embedded Web Server User Guide* for more information. Before you create a new user, you should review information on the security features provided with SANtegrity and RADIUS Servers, including authentication for the various interfaces such as Web (HTTP), CLI, Serial Port, E Port, N Port, and OSMS.

---

To configure passwords:

1. Select **Configure > Security** to display the Authorize Users (Auth Users) tab (Figure 51).

Configure: Refresh 2 / 9 / 05 at 14:36:42

Ports Switch Management Zoning Security Performance

Auth Users Auth Settings Port Binding Switch Binding Fabric Binding >>

Interface: Web GO

**New User Record**

Username	Password	Confirm Password	Role	Include CLI
			Administrator	<input type="checkbox"/>

Add User

**Current User Records**

Username	New Password	Confirm New Password	Role	CLI	Delete User
Administrator			Administrator	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Operator			Operator	<input checked="" type="checkbox"/>	<input type="checkbox"/>

Activate


**Figure 51** Auth Users tab

2. Under Current User Records, enter the new password in the New Password column. Use 16 or fewer alphanumeric characters.
3. Enter the new password in the Confirm New Password column.
4. Select the appropriate role for the user from the Role drop-down list: **Administrator**, **Operator**, or **No Role**.
5. Click the **Include CLI** box to authorize the user to use the CLI.
6. Click **Activate** to activate save the information. The message Your changes to the Auth Users configuration have been successfully activated. Login may be required. is displayed.

## Reset configuration data

1. Notify the customer the switch is to be set offline. Ensure that the customer's system administrator quiesces Fibre Channel frame traffic through the switch and sets attached FC-AL devices offline.
2. At the HAFM appliance, open the HAFM appliance application.
3. Set the switch offline. For instructions, refer to "Set the switch offline" on page 40.
4. At the HAFM application's physical map, right-click the product icon representing the switch for which a configuration file is to be reset to factory default settings, then select **Element Manager** from the pop-up menu. The application opens.


5. Select the **Reset Configuration** option from the Maintenance menu. The Reset Configuration dialog box is displayed (Figure 52).



**Figure 52** Reset Configuration dialog box


6. Click **Reset** to initiate the reset operation and close the dialog box.
7. The switch IP address resets to the default address of 10.1.1.10.
  - If the configured IP address (prior to reset) was the same as the default address, the switch-to-management appliance Ethernet link is not affected and the procedure is complete.
  - If the configured IP address (prior to reset) was not the same as the default address, the switch-to-management appliance Ethernet link drops and server communication is lost. Continue to the next step.
8. To change the switch IP address and restart the management appliance session, go to [step 10](#).
9. To restart a management appliance session using the default IP address of 10.1.1.10:
  - a. Close the Element Manager application and return to the HAFM application.
  - b. A grey square with a yellow exclamation mark appears adjacent to the icon representing the reset switch, indicating switch is not communicating with the HAFM appliance.

- c. At the HAFM application, select **Discover > Setup**. The Discover Setup page is displayed (Figure 53).



**Figure 53** Discover Setup page

- d. Select (highlight) the entry representing the reset switch in the Available Addresses window and click **Change**. The Domain Information dialog box is displayed (Figure 54).



**Figure 54** Domain Information dialog box

- Enter **10.1.1.10** in the IP Address field and click **OK**. Entries at the Discover Setup dialog box reflect the new IP address.
- At the Discover Setup dialog box, click **OK**. Switch-to-management appliance communication is restored and the procedure is complete.

**10.** Change the switch IP address and restart the management appliance session as follows:

- a.** A grey square with a yellow exclamation mark appears adjacent to the icon representing the reset switch, indicating switch is not communicating with the management appliance.
- b.** Delete the icon representing the reset switch. At the HAFM application, select **Setup** from the Discover menu. The Discover Setup dialog box is displayed ([Figure 53](#) on page 85).
- c.** Select (highlight) the entry representing the reset switch in the Available Addresses window and click **Remove**.
- d.** At the Discover Setup dialog box, click **OK**. The switch is no longer defined to the management appliance.
- e.** Change a switch's IP address through the maintenance port at the rear of the switch. For instructions, refer to "[Configure network information](#)" on page 79.
- f.** Identify the switch to the HAFM application. For instructions, refer to "[Configure switch identification](#)" on page 74.
- g.** Switch-to-management appliance communication is restored and the procedure is complete.

## 4 Manage firmware versions


The Edge Switch 2/32 internal operating code is downloaded from the HAFM appliance and stored on a CTP2 card. Up to eight versions can be stored on HAFM appliance hard drive and made available for download to an edge switch. This chapter contains information on the following firmware management tasks:

- [Determine a switch firmware version](#), page 87
- [Add a firmware version](#), page 88
- [Modify a Firmware version description](#), page 90
- [Delete a firmware version](#), page 90
- [Download a firmware version to a switch](#), page 91
- [Back up the configuration](#), page 92

### Determine a switch firmware version

To determine a switch firmware version from the management appliance (Element Manager application):

1. At the management appliance, open the HAFM application.
2. At the HAFM application's physical map, right-click the product icon representing the switch to be inspected for firmware version, then select **Element Manager** from the pop-up menu. The application opens.
3. Select the **Firmware Library** from the Maintenance menu. The Firmware Library dialog box is displayed ([Figure 55](#)).




**Figure 55** Firmware Library dialog box

4. The active firmware version is displayed at the lower left corner of the dialog box in **XX.YY.ZZ** format. The **XX** is the version level, **YY** is the release level, and **ZZ** is the patch level.
5. Click **Close**.

## Add a firmware version

The firmware version shipped with the edge switch is provided on the Edge Switch 2/32 documentation CD. Subsequent firmware versions to upgrade the edge switch are provided to customers through the web site web site.

---


 **NOTE:** When adding a firmware version, follow procedural information in the release notes that accompany the firmware version. This information supplements information provided in this general procedure.

---

Use these steps to add an edge switch firmware version to the library stored on the HAFM appliance hard drive:

1. Obtain the new firmware version from the web site web site:

---

 **NOTE:** The following path is subject to change.

---

- a. At the HAFM appliance or other personal computer (PC) with Internet access, open the HP web site. The uniform resource locator (URL) is <http://www.hp.com/country/us/eng/storage.html>.
  - b. Locate the **Networked storage** section of the Web page.
  - c. Under **Networked storage**, locate the **By type** subsection.
  - d. Click **SAN infrastructure**. The **SAN infrastructure** page appears.
  - e. Locate the **Fibre Channel Switches** section.
  - f. Go to the **M-Series Fabric** subsection and click **Edge Switch 2/32**. The **HP StorageWorks Edge Switch 2/32** page appears.
  - g. Locate the **Product information** section and click **Software, firmware & drivers**. The **specify operating system** page for your product appears.
  - h. Locate the **select operating system** section and click **Cross operating system (BIOS, Firmware, Diagnostics, etc.)**. The **download drivers and software** page for the selected product appears.
  - i. Locate the **Firmware** section and click **download** next to the firmware you want to download. The Windows Save As dialog box appears  
Verify or correct the directory path specified in the Save in field and the file name specified in the File name field.
  - j. Click **Save**. The new firmware version is downloaded and saved to the HAFM appliance or PC hard drive.
  - k. If the new firmware version was downloaded to a PC (not the HAFM appliance), transfer the firmware version file to the switch by backup disk, CD-ROM, or other electronic means.
2. At the HAFM application's physical map, right-click the product icon representing the switch for which a firmware version is to be added, then select **Element Manager** from the pop-up menu. The application opens.




3. Select **Firmware Library** from the Maintenance menu. The Firmware Library dialog box is displayed (Figure 56).




**Figure 56** Firmware Library dialog box

4. Click **New**. The New Firmware Version dialog box is displayed (Figure 57).



**Figure 57** New Firmware Version dialog box

5. Select the desired firmware version file (downloaded in step 1) from the HAFM appliance backup drive, CD-ROM drive, or hard drive. Verify that the correct directory path and filename display in the File name field and click **Save**. The New Firmware Description dialog box is displayed (Figure 58).



**Figure 58** New Firmware Description dialog box

6. Enter a description (up to 24 characters in length) for the new firmware version and click **OK**. HP recommends the description include the installation date and text that uniquely identifies the firmware version.
7. Click **OK**. The File Transfer message box is displayed. As the transfer progresses, a progress bar travels across the message box to show percent completion.
8. A Transfer Complete message box is displayed indicating the new firmware version is stored on the HAFM appliance hard drive. Click **Close** to close the message box.
9. The new firmware version and associated description display in the Switch Firmware Library dialog box.

10. Click **Close**.

11. To send the firmware version to an edge switch, see ["Download a firmware version to a switch"](#) on page 91.

## Modify a Firmware version description

Use these steps to modify the description of an edge switch firmware version in the library stored on the HAFM appliance hard drive:

1. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
2. Double-click the icon representing the edge switch for which the firmware version description will be modified. The Hardware View page for the selected edge switch is displayed.
3. Select **Maintenance > Firmware Library**. The Switch Firmware Library dialog box is displayed ([Figure 58](#)).
4. Select the firmware version to be modified and click **Modify**. The Modify Firmware Description dialog box is displayed ([Figure 59](#)).



**Figure 59** Modify Firmware Description dialog box

5. Enter a modified description (up to 24 characters in length) for the firmware version and click **OK**. HP recommends the description include the installation date and text that uniquely identifies the firmware version.
6. The new description for the firmware version is displayed in the Switch Firmware Library dialog box.
7. Click **Close**.

## Delete a firmware version

Use these steps to delete a firmware version from the library stored on the HAFM appliance hard drive:

1. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
2. Double-click the icon representing the edge switch from which the firmware version will be deleted. The Hardware View page for the selected edge switch is displayed.
3. Select **Maintenance > Firmware Library**. The Switch Firmware Library dialog box is displayed ([Figure 55](#)).
4. Select the firmware version to be deleted and click **Delete**. A confirmation dialog box is displayed.
5. Click **OK**. The selected firmware version is deleted from the Switch Firmware Library dialog box.
6. Click **Close**.

## Download a firmware version to a switch

This procedure downloads a selected firmware version from the HAFM appliance library to an edge switch managed by the open instance of the Element Manager application. The procedure applies to an Edge switch with one CTP2 card, or a director with two (redundant) CTP2 cards. The process occurs concurrently without taking the edge switch offline or disrupting operation. The new firmware version takes effect when control is passed from the active to the backup CTP2 card. Although edge switch operation is not affected, name server, alias server, and login server functions are momentarily unavailable during CTP2 card switchover. Although traffic is not disrupted, the green port LEDs will flicker or blink during the IPL portion of this operation as control is passed to the other CTP2 card.



**NOTE:** When downloading a firmware version, follow procedural information in the release notes that accompany the firmware version. This information supplements information provided in this general procedure.

Use these steps to download a firmware version to an edge switch:

1. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
2. Before downloading a selected firmware version to an edge switch, ensure that the required, compatible version of the HAFM application is running on the HAFM appliance. Refer to the release notes that shipped with HAFM.
  - a. Select **Help > About**. The About dialog box is displayed with the HAFM application version listed. Click **OK** to close the dialog box.
  - b. If required, install the correct version of the HAFM application.
3. At the HAFM application's physical map, right-click the product icon representing the switch for which a firmware version is to be downloaded, then select **Element Manager** from the pop-up menu. The application opens.
  - a. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
  - b. Double-click the icon representing the edge switch for which the configuration file will be backed up. The Hardware View page for the selected edge switch is displayed.
  - c. Select **Maintenance > Backup & Restore Configuration**. The Backup and Restore Configuration dialog box is displayed.
  - d. Click **Backup**. When the backup process finishes, the Backup Complete dialog box is displayed.
  - e. Click **OK** to close the dialog box and return to the Hardware View page.
4. Select **Maintenance > Firmware Library**. The Switch Firmware Library dialog box is displayed (Figure 56).

5. Select the firmware version to be downloaded and click **Send**. The send function verifies existence of certain edge switch conditions before the download process begins. If an error occurs, a message is displayed indicating the problem must be fixed before firmware is downloaded. Conditions that terminate the process include:

- A redundant CTP2 card failure.
- The firmware version is being installed to the edge switch by another user.
- The edge switch-to-HAFM appliance fails or times out.

If a problem occurs and a corresponding message is displayed, refer to the *HP StorageWorks Edge Switch 2/32 service manual* for specific information on isolating the problem. If no error occurs, the Send Firmware confirmation box is displayed.

6. Click **Yes**. The Send Firmware dialog box is displayed.

As the download begins, a `Writing data to FLASH` message is displayed at the top of the dialog box, followed by a `Sending Files` message. This message remains as a progress bar travels across the dialog box to show percent completion of the download. The bar progresses to 50% when the last file is transmitted to the first CTP2 card. The bar remains at the 50% point until the edge switch performs an Initial Program Load (IPL) (indicated by an `IPLing` message).

During the IPL, the edge switch-to-HAFM appliance link drops momentarily and the following occur at the Element Manager:

- As the network connection drops, the edge switch Status table turns yellow, the Status field displays `No Link`, and the State field displays a reason message.
- The alert panel at the bottom of the navigation control panel displays a grey square, indicating edge switch status is unknown.
- Illustrated FRUs in the Hardware View page are removed, and then displayed again as the connection is re-established.

After the IPL, a `Synchronizing CTP2s` message is displayed. This message remains as files are transmitted to the second CTP2 card and the progress bar travels across the dialog box to 100%. When the download reaches 100%, a `Send firmware complete` message is displayed.


7. Click **Close** to close the dialog box.
8. Click **Close** to complete the operation.

## Back up the configuration

Use these steps to back up the configuration file on the HAFM appliance.

1. At the HAFM appliance, open the HAFM application. The Products View is displayed.
2. At the HAFM application's physical map, right-click the product icon representing the switch for which a configuration file is to be backed up, then select **Element Manager** from the pop-up menu. The application opens.
3. Select **Maintenance > Backup & Restore Configuration**. The Backup and Restore Configuration dialog box is displayed.

4. Click **Backup**. An Information dialog box is displayed, indicating the backup operation was initiated (Figure 60).



**Figure 60** Information dialog box

5. Click **OK** to complete the backup operation and close the dialog box.

## Restore the Configuration

To restore the switch configuration file from the management appliance:

1. Notify the customer the switch is to be set offline. Ensure that the customer's system administrator quiesces Fibre Channel frame traffic through the switch and sets attached FC-AL devices offline.
2. Set the switch offline. For instructions, refer to "[Set the switch offline](#)" on page 40.
3. At the HAFM appliance, open the HAFM application.
4. At the HAFM application's physical map, right-click the product icon representing the switch for which a configuration file is to be restored, then select **Element Manager** from the pop-up menu. The application opens.
5. Select **Backup & Restore Configuration** from the Maintenance menu. The Backup and Restore Configuration dialog box is displayed.
6. Click **Restore**. A Warning dialog box is displayed, indicating the existing configuration file is to be overwritten.
7. Click **Yes**. A Restore dialog box is displayed, indicating the restore operation is in progress.
8. When the operation finishes, the Restore dialog box displays a Restore complete message. Click **Close** to close the dialog box.



---

## A Regulatory compliance and safety

This appendix covers the following topics:

- [Federal Communications Commission notice](#), page 95
- [Regulatory compliance identification numbers](#), page 97
- [Laser device](#), page 97
- [Canadian notice \(avis Canadien\)](#), page 98
- [European Union notice](#), page 98
- [BSMI notice](#), page 98
- [Japanese notice](#), page 99
- [Korean notices](#), page 99
- [Battery replacement notice](#), page 99
- [Taiwan battery recycling notice](#), page 100
- [Power cords](#), page 100
- [Japanese power cord notice](#), page 101
- [Electrostatic discharge](#), page 101

### Regulatory compliance

#### Federal Communications Commission notice

Part 15 of the Federal Communications Commission (FCC) Rules and Regulations has established Radio Frequency (RF) emission limits to provide an interference-free radio frequency spectrum. Many electronic devices, including computers, generate RF energy incidental to their intended function and are, therefore, covered by these rules. These rules place computers and related peripheral devices into two classes, A and B, depending upon their intended installation. Class A devices are those that may reasonably be expected to be installed in a business or commercial environment. Class B devices are those that may reasonably be expected to be installed in a residential environment (i.e., personal computers). The FCC requires devices in both classes to bear a label indicating the interference potential of the device as well as additional operating instructions for the user.

The rating label on the device shows which class (A or B) the equipment falls into. Class B devices have an FCC logo or FCC ID on the label. Class A devices do not have an FCC logo or FCC ID on the label. Once the class of the device is determined, refer to the following corresponding statement.

#### Class A equipment

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at personal expense.

## Class B equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit that is different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

## Declaration of conformity for products marked with the FCC logo, United States only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding your product, visit <http://www.hp.com>.

For questions regarding this FCC declaration, contact us by mail or telephone:

- Hewlett-Packard Company  
P.O. Box 692000, Mailstop 510101  
Houston, Texas 77269-2000
- 1-281-514-3333

To identify this product, refer to the part, Regulatory Model Number, or product number found on the product.

## Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hewlett-Packard Company may void the user's authority to operate the equipment.

## Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods in order to maintain compliance with FCC Rules and Regulations.



## Regulatory compliance identification numbers

For the purpose of regulatory compliance certifications and identification, your product has been assigned a unique Regulatory Model Number. The RMN can be found on the product nameplate label, along with all required approval markings and information. When requesting compliance information for this product, always refer to this RMN. The Regulatory Model Number should not be confused with the marketing name or model number of the product.

## Laser device

All HP systems equipped with a laser device comply with safety standards, including International Electrotechnical Commission (IEC) 825. With specific regard to the laser, the equipment complies with laser product performance standards set by government agencies as a Class 1 laser product. The product does not emit hazardous light.

## Laser safety warning

---

⚠ **WARNING!** To reduce the risk of exposure to hazardous radiation:

- Do not try to open the laser device enclosure. There are no user-serviceable components inside.
  - Do not operate controls, make adjustments, or perform procedures to the laser device other than those specified herein.
  - Allow only HP authorized service technicians to repair the laser device.
- 

## Certification and classification information

This product contains a laser internal to the fiber optic (FO) transceiver for connection to the Fibre Channel communications port.

In the USA, the FO transceiver is certified as a Class 1 laser product conforming to the requirements contained in the Department of Health and Human Services (DHHS) regulation 21 CFR, Subchapter J. A label on the plastic FO transceiver housing indicates the certification.

Outside the USA, the FO transceiver is certified as a Class 1 laser product conforming to the requirements contained in IEC 825-1:1993 and EN 60825-1:1994, including Amendment 11:1996 and Amendment 2:2001.

## Laser product label

The optional label in [Figure 61](#) or equivalent may be located on the surface of the HP supplied laser device.



This optional label indicates that the product is classified as a CLASS 1 LASER PRODUCT. This label may appear on the laser device installed in your product.

**Figure 61** Class 1 laser product label

## International notices and statements

### Canadian notice (avis Canadien)

#### Class A equipment

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

#### Class B equipment

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### European Union notice

Products bearing the CE marking comply with the EMC Directive (89/336/EEC) and the Low Voltage Directive (73/23/EEC) issued by the Commission of the European Community and if this product has telecommunication functionality, the R&TTE Directive (1999/5/EC).

Compliance with these directives implies conformity to the following European Norms (in parentheses are the equivalent international standards and regulations):

- EN55022 (CISPR 22) - Electromagnetic Interference
- EN55024 (IEC61000-4-2, IEC61000-4-3, IEC61000-4-4, IEC61000-4-5, IEC61000-4-6, IEC61000-4-8, IEC61000-4-11) - Electromagnetic Immunity
- Power Quality:
  - EN61000-3-2 (IEC61000-3-2) - Power Line Harmonics
  - EN61000-3-3 (IEC61000-3-3) - Power Line Flicker
- EN60950 (IEC60950) - Product Safety
- Also approved under UL 60950/CSA C22.2 No. 60950-00, Safety of Information Technology Equipment.

### BSMI notice

警告使用者:

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

## Japanese notice

ご使用になっている装置にVCCIマークが付いていましたら、次の説明文をお読み下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。  
取扱説明書に従って正しい取り扱いをして下さい。

VCCIマークが付いていない場合には、次の点にご注意下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

## Korean notices

### A급 기기 (업무용 정보통신기기)

이 기기는 업무용으로 전자파적합등록을 한 기기이오니  
판매자 또는 사용자는 이 점을 주의하시기 바라며, 만약  
잘못판매 또는 구입하였을 때에는 가정용으로 교환하시기  
바랍니다.

### B급 기기 (가정용 정보통신기기)

이 기기는 가정용으로 전자파적합등록을 한 기기로서  
주거지역에서는 물론 모든지역에서 사용할 수 있습니다.

## Safety


### Battery replacement notice

Your computer is equipped with a lithium manganese dioxide, a vanadium pentoxide, or an alkaline internal battery or battery pack. There is a danger of explosion and risk of personal injury if the battery is incorrectly replaced or mistreated. Replacement is to be done by an HP authorized service provider using the HP spare part designated for this product. For more information about battery replacement or proper disposal, contact an HP authorized reseller or HP authorized service provider.

---

**⚠ WARNING!** Your computer contains an internal lithium manganese dioxide, a vanadium pentoxide, or an alkaline battery pack. There is risk of fire and burns if the battery pack is not properly handled. To reduce the risk of personal injury:

- Do not attempt to recharge the battery.
  - Do not expose to temperatures higher than 60°C.
  - Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.
  - Replace only with the HP spare part designated for this product.
- 



Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. To forward them to recycling or proper disposal, please use the public collection system or return them to HP, an authorized HP Partner, or their agents.

For more information about battery replacement or proper disposal, contact an HP authorized reseller or service provider.

## Taiwan battery recycling notice



廢電池請回收

The Taiwan EPA requires dry battery manufacturing or importing firms in accordance with Article 15 of the Waste Disposal Act to indicate the recovery marks on the batteries used in sales, giveaway or promotion. Contact a qualified Taiwanese recycler for proper battery disposal.

## Power cords

The power cord set must meet the requirements for use in the country where the product was purchased. If the product is to be used in another country, purchase a power cord that is approved for use in that country.

The power cord must be rated for the product and for the voltage and current marked on the product electrical ratings label. The voltage and current rating of the cord should be greater than the voltage and current rating marked on the product. In addition, the diameter of the wire must be a minimum of 1.00 mm<sup>2</sup> or 18 AWG, and the length of the cord must be between 1.8 m (6 ft) and 3.6 m (12 ft). If you have questions about the type of power cord to use, contact an HP authorized service provider.

---

**NOTE:** Route power cords so that they will not be walked on and cannot be pinched by items placed upon or against them. Pay particular attention to the plug, electrical outlet, and the point where the cords exit from the product.

---

## Japanese power cord notice

製品には、同梱された電源コードをお使い下さい。  
同梱された電源コードは、他の製品では使用出来ません。

## Electrostatic discharge

To prevent damage to the system, be aware of the precautions you need to follow when setting up the system or handling parts. A discharge of static electricity from a finger or other conductor may damage system boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device.

## Preventing electrostatic damage

To prevent electrostatic damage, observe the following precautions:

- Avoid hand contact by transporting and storing products in static-safe containers.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free workstations.
- Place parts on a grounded surface before removing them from their containers.
- Avoid touching pins, leads, or circuitry.
- Always be properly grounded when touching a static-sensitive component or assembly (see ["Grounding methods"](#) on page 101).


## Grounding methods

There are several methods for grounding. Use one or more of the following methods when handling or installing electrostatic-sensitive parts:

- Use a wrist strap connected by a ground cord to a grounded workstation or computer chassis. Wrist straps are flexible straps with a minimum of 1 megohm ( $\pm 10$  percent) resistance in the ground cords. To provide proper ground, wear the strap snug against the skin.
- Use heel straps, toe straps, or boot straps at standing workstations. Wear the straps on both feet when standing on conductive floors or dissipating floor mats.
- Use conductive field service tools.
- Use a portable field service kit with a folding static-dissipating work mat.

If you do not have any of the suggested equipment for proper grounding, have an HP authorized reseller install the part.

---

 **NOTE:** For more information on static electricity, or assistance with product installation, contact your HP authorized reseller.

---



# B Technical specifications

This appendix contains the following information:

- [Factory defaults](#), page 103
- [Physical dimensions](#), page 105
- [Environmental specifications](#), page 105
- [Power requirements](#), page 106
- [Operating tolerances](#), page 106
- [Laser information](#), page 107

## Factory defaults

[Table 4](#) lists the defaults for the passwords, and IP, subnet, and gateway addresses.

**Table 4** Factory-set defaults

Item	Default
User name	Administrator
Customer password	password
Maintenance password	level-2
IP address	10.1.1.10
Subnet mask	255.0.0.0
Gateway address	0.0.0.0

[Table 5](#) provides the Edge Switch factory-default values for Reset Configuration option.

**Table 5** Switch factory-default values for reset configuration option

Configuration	Description	Default
Identification	Switch Name	NULL string
	Switch Description	"Fibre Channel Switch"
	Switch Contact	"End User Contact (please configure)"
	Switch Location	"End User Contact (please configure)"

**Table 5** Switch factory-default values for reset configuration option (continued)

Configuration	Description	Default
Ports	Port Names	NULL strings
	Port Blocked States	Unblocked
	FAN	Enabled
	LIN Alerts (see page 49)	Enabled
	Ports enabled	8
Switch addressing	IP Address	10.1.1.10
	Subnet Mask	255.0.0.0
	Gateway Address	0.0.0.0
	MAC Address	PROM value
Operating mode	Must select one of two modes: Open Fabric 1.0 or McData Fabric 1.0. HP recommends using the Open Fabric 1.0 mode. McData Fabric 1.0 must be homogeneous.	Open Fabric 1.0 mode
Operating parameters	Preferred Domain ID	1
	R_A_TOV	10 seconds (100 tenths)
	E_D_TOV	2 seconds (20 tenths)
	Switch Priority	Default
	Switch Speed	2 Gb/sec
	Rerouting Delay	Enabled
SNMP	SNMP Communities	"public" — 5 NULL strings
	SNMP Write Authorizations	Read only per community
	Trap Recipient IP Addressees	0 for each
	UDP Port	162
	SNMP Authorization Trap State	disabled
Management appliance	Active Equal Saved State	Disabled
	Remote Offline Control State	Disabled



**Table 5** Switch factory-default values for reset configuration option (continued)

Configuration	Description	Default
Zoning	Number of Zone Members	0
	Number of Zones	0
	Number of Zone Sets	0
	Zone Names	None
	Zone Sets Names	None
	Zone Members	None
	Default Zone State	Disabled
	Active Zone Set State	Disabled
	Active Zone Set Name	NULL string

## Physical dimensions

Table 6 lists Edge Switch 2/32 dimensions.

**Table 6** Dimensions

Dimension	Size
Height	6.47 cm (2.55 in)
Width	44.5 cm (17.5 in)
Depth	66.8 cm (26.7 in)
Weight	15.4 kg (34 lb)
Shipping Weight	17.2 kg (38 lb)

## Environmental specifications

Table 7 lists environmental ranges for shipping, storing, and operating the HP StorageWorks Edge Switch 2/32.

**Table 7** Environmental specifications

Specification	Shipping	Storage	Operating
Weight	17.2 kg (38 lb)	15.4 kg (34 lb)	15.4 kg (34 lb)
Temperature	-40° F to 140° F (-40° C to 60° C)	34° F to 140° F (1° C to 60° C)	40°F to 104°F (4°C to 40 °C)
Humidity	5% to 100%	5% to 80%	8% to 80%

**Table 7** Environmental specifications (continued)

Specification	Shipping	Storage	Operating
Maximum wet-bulb temperature	84° F (29° C)	84°F (29°C)	81°F (27°C)
Altitude	40,000 ft (12,192 m)	40,000 ft (12,192 m)	10,000 ft (3,048 m)

## Power requirements

**Table 8** lists Edge Switch 2/32 power requirements.

**Table 8** Power requirements

Specification	Value
Input voltage	100 to 240 VAC
Input frequency	47 to 63 Hz

## Operating tolerances

**Table 9** lists heating and cooling specifications, shock and vibration tolerance, acoustical noise, and inclination.

**Table 9** Operating tolerances

Specification	Value
Heat dissipation	836 BTU/hr (32 ports)
Cooling airflow clearances	Right and left sides: No clearance required Front and rear: 7.6 cm (3.0 in) Top and bottom: No clearance required
Shock and vibration tolerance	60 Gs for 10 milliseconds without nonrecoverable errors
Acoustical noise	6.6 Bels
Inclination	10° maximum

## Laser information

Three configurations of cards with fixed optics will be provided for each of the connector types: four extended long-wave ports, four long-wave ports, and four short-wave ports.

**Table 10** Laser specifications—2 Gb

Part number	Transceivers on UPM card	Wave length	Media/ distance	Standard
300836-B21 Long wave — 35 km	4 Extended Long wave	1310 nm	9/125 $\mu\text{m}$ Single-mode: 1 m–35 Km	100-SM-LL-L
300835-B21 Long wave — 10 km	4 Long wave	1310 nm	9/125 $\mu\text{m}$ Single-mode: 1 m–10 Km	100-SM-LL-L
300834-B21 Short wave	4 Short wave	850 nm	50/125 $\mu\text{m}$ Multimode: 2 m–500 m  62.5/125 $\mu\text{m}$ Multimode: 1 m–200 m	100-M5-SN-I



# Index

- A**
  - accumulators 100
  - active zone set state, default value 105
  - additional port function, reset by configuration reset 30
  - addresses, default values 104
  - alerts, introduction 14
  - alkaline battery warning 100
  - asynchronous RS-232 null modem cable 21
  - audience 9
  - authorized reseller, HP 11
- B**
  - backing up switch configuration file 92
  - batteries
    - recycling or disposal 100
    - replacement
      - notice 99
      - warning 100
    - Taiwan EPA recycling and disposal 100
  - bb\_credit 45
  - beaconing, introduction 15
  - binding ports 52
  - boot straps, using 101
  - brackets
    - and rails 26
    - mounting 27
  - BSMI, regulatory compliance notice 98
- C**
  - cables
    - FCC compliance statement 96
    - shielded 96
  - call-home feature
    - introduction 15
    - overview 56
  - certification and classification information, laser 97
  - checklist, rack mount 26
  - Class A equipment, Canadian compliance statement 98
  - Class B equipment, Canadian compliance statement 98
  - clock speed, processor 67
  - command line interface
    - description 14
    - disable using EWS 82
    - enable using EWS 82
  - configuration data, backing up 64
  - configure
    - Ethernet events 56
    - fabric parameters 44
    - fabric parameters dialog box 45
    - feature key 64
    - management appliance 64
    - port addresses, FICON 52
    - switch parameters 42
    - switch parameters dialog box 42
  - configure menu
    - enable telnet 64
    - management appliance 64
  - Configure Ports
    - Open Systems management style 47
    - S/390 Mode 51
  - Configure SNMP Trap Message Recipients 80
  - connectors and indicators 18
  - conventions
    - document 10
    - text symbols 10, 25, 28
  - cord. See power cord
  - current rating 100
- D**
  - data collection 15
  - declaration of conformity 96
  - defaults
    - management appliance 104
    - operating parameters 104
    - SNMP 104
  - diagnostic software, introduction 15

- dialog boxes
  - configure fabric parameters 45
  - configure switch parameters 42
- disposal, battery 100
- disposal, Taiwan EPA battery 100
- dissipating floor mats 101
- document
  - conventions 10
  - prerequisites 9
  - related documentation 9
- domain
  - ID
    - insistent 43
    - preferred 43
  - RSCNs 44
- downloading firmware 91
- E**
- e\_d\_tov 46
  - default value 104
  - fabric segmentation 46
  - less than r\_a\_tov 46
  - multiswitch fabrics 46
  - rerouting delay 44
- E\_port segmentation, preferred domain ID 43
- electrostatic damage prevention 101
- electrostatic discharge. See ESD
- Element Manager 14
- element manager
  - configuring e-mail notification 54
  - configuring SNMP trap message recipients 53
  - configuring switch identification 40
- e-mail notification
  - configuring, element manager 54
  - introduction 15
- embedded web server. See EWS
- enable
  - ports, factory default 30
  - telnet 64
- ESD (electrostatic discharge)
  - obtaining additional information 101
  - precautions 101
  - prevention measures 101
  - storing products 101
  - transporting products 101
  - types of damage from 101
- ESD wrist strap 21

- Ethernet
  - events, configure at HAFM appliance 56
  - events, enable at HAFM appliance 56
  - hub, unpacking, inspecting, and installing 67
  - LAN, connector 19
  - network adapter 68
- European Union, regulatory compliance notice 98
- EWS
  - configuring
    - date and time 75, 76
    - network information 79
    - SNMP trap message recipients 80
    - switch identification 74
    - switch ports 73
    - user rights 82
  - defined 14
  - launching 71
- F**
- fabric parameters
  - bb\_credit 45
  - configuring 44
  - e\_d\_tov 46
  - interop mode 47
  - r\_a\_tov 45
  - switch priority 46
- fabric segmentation
  - e\_d\_tov 46
  - preferred domain ID 43
- fan LEDs 19
- FCC (Federal Communications Commission)
  - Class A Equipment, compliance notice 95
  - Class B Equipment, compliance notice 96
  - declaration of conformity 96
  - modifications 96
  - notice 95
- feature key, configuring 64
- Federal Communications Commission. See FCC
- fiber-optic
  - cleaning kit 21
  - protective plug 20
- fibre channel addresses 43
- FICON
  - configuring port addresses 52
  - devices, communication 41
  - management appliance 64

- firmware
  - deleting version 90
  - determining version 87
  - modifying description 90
  - release notes 88
- floor mats, dissipating 101
- frames, routing of 43
- FRUs
  - fans 18
  - power supplies 18
  - SFP transceivers 18
  - status LEDs 19

## G

- gateway address
  - configuring 30
  - default 103
- German noise declaration 99
- ground strap specifications 101
- grounding
  - methods 101
  - straps, wearing 101
  - suggested equipment for 101

## H

- HA PA-RISC processor 67
- HAFM appliance
  - configuring switch 35
  - defined 14
  - recording and verifying restoration information 35
  - remote location 67
  - setting offline 40
  - setting the switch online 39
  - verifying communication to switch 36
- hard drives, remote workstation 67
- hardware, mounting 26
- heel straps, using 101
- help, obtaining 11, 12
- High Availability Fabric Manager See HAFM appliance
- homogeneous fabric, interop mode 47
- hop counts 43

## HP

- address for
  - FCC questions 96
- authorized reseller 11
- series number 97
- storage web site 12
- Subscriber's choice web site 11
- technical support 11
- telephone number
  - FCC questions 96
- HP-UX operating system 67
- HyperTerminal 21

## I

- IBM AIX operating system 67
- identification, default values 103
- IML button 18
- insistent domain ID 43
- Installation options 23
- installation tasks
  - backing-up configuration data 64
  - cabling Fibre Channel ports 65
  - configuring
    - network addresses 30
    - switch to the HAFM appliance 35
  - connecting switch to fabric switch 65
  - LAN-connecting the switch 34
  - recording and verifying HAFM appliance restoration information 35
  - setting switch date and time 38
  - unpacking and inspecting switch 24
  - unpacking, inspecting, and installing Ethernet hub 67
  - verify installation requirements 23
  - verifying switch-to-HAFM appliance communication 36
- Internet Explorer 68
- interop mode 47
- IP address
  - configuring 30
  - default 103
  - default value 104

## J

### Japan

- regulatory compliance notice 99

## K

- Korean, regulatory compliance notice 99

## L

- label, laser 97

### LAN

- connecting the switch 34
- connector 19

### laser

- international certification and classification information 97
- product label 97
- radiation, warning 97
- regulatory compliance notice 97

### LEDs

- fans 19
- FRU status 19
- port SFPs 19
- power supply 19
- PWR LED 19

- LIN alerts, default values 104

- Linux operating system 67

- lithium battery 99

- logs, introduction 14

### loopback plug

- multimode 20
- singlemode 20

## M

### MAC addresses

- default 104
- description 30

- maintenance port 15, 19

### management

- appliance
  - default values 104
  - FICON 64
  - open systems 64
- style, open systems 41
- switch 14

- memory, remote workstation 67

- Microsoft Internet Explorer 68

- mounting hardware 26

- multiswitch fabric 16

- e\_d\_tov 46

- principal switch 46

- rerouting delay 43

## N

- Netscape Navigator 68

- network adapter 68

- network addresses, configuring 30

- network information, configuring from EWS 79

- noise declaration, German 99

- null modem cable 21

- NVRAM 42, 44

## O

- online state, setting 39

- open fabric 1.0 interop mode 47

### open systems

- management appliance 64
  - management style 41

- operating parameters, default values 104

- OSI devices, communication 41

## P

### parts

- proper handling 101

- storing 101

- transporting 101

- password, default 103

- port addresses, FICON, configuring 52

### ports

- binding 52

- blocked states, default value 104

- cabling 65

- default values 104

- factory defaults 30

- loopback diagnostic tests, fiber-optic

- loopback plug 20

- UDP, default value 104

### power cord

- compliance notice 100

- current rating 100

- replacement 100

- set 100

- voltage rating 100



- power supplies 18
  - LEDs 19
  - requirements 106
- POWER3 microprocessor 67
- PowerPC microprocessor 67
- preferred domain ID 43
  - default value 104
- prerequisites 9
- preventing electrostatic damage 101
- principal switch, determining 46
- priority, default value 104
- ProComm Plus 21
- protective plug 20

## R

- r\_a\_tov 45
  - default value 104
  - greater than e\_d\_tov 46
- rack mount
  - checklist 26
  - installing brackets 27
  - installing the switch 29
  - required tools 27
  - slide rails 27
- rack stability, warning 11
- rack types 26
- rails
  - and brackets 26
  - mounting 27
- recycling, battery 100
- recycling, Taiwan EPA battery 100
- Red Hat operating system 67
- regulatory compliance
  - information number 97
  - notices 95
    - BSMI 98
    - Class A 95
    - Class B 96
    - European Union 98
    - HP series number 97
    - Japan 99
    - Korean 99
  - lasers 97
  - modifications 96
  - shielded cables 96
- related documentation 9
- release notes 88

- remote
  - offline control states, default value 104
- replacing a power cord 100
- rerouting delay 43
- RFI/EMI connector hoods 96
- routing delay, default value 104

## S

- safety
  - ESD grounding cable with wrist strap 21
  - fiber-optic protective plug 20
- SANtegrity Binding features 47
- series number, regulatory compliance 97
- serviceability features 14
- setting, online state 39
- SFP transceivers 18
  - LEDs 19
  - longwave 18
  - shortwave 18
- slide rails
  - mounting 27
- SNMP
  - authorization trap states, default value 104
  - communities, default value 104
  - configuring trap message recipients, EWS 80
  - configuring trap recipients, element manager 53
  - default values 104
  - introduction 15
  - write authorizations, default value 104
- speeds, default value 104
- static
  - electricity 101
- static-dissipating work mat 101
- static-safe containers
  - storing products 101
  - transporting products 101
- static-sensitive devices 101
- straps, ground
  - boot 101
  - heel 101
  - toe 101
- subnet mask
  - configuring 30
  - default 103
- Subscriber's choice, HP 11
- Sun Solaris operating system 67
- suppress RSCNs on zone set activations 44

- switch
  - binding 47
  - configuring parameters 42
  - connecting to fabric switch 65
  - connectors and indicators 18
  - default speed value 104
  - error-detection, reporting, and serviceability features 14
  - fans 18
  - fibre channel addresses 43
  - firmware 88
  - FRUs 16
  - installing in cabinet 29
  - LAN connecting 34
  - LEDs 19
  - maintenance port 19
  - management 14
  - multiswitch fabric 16
  - network addresses 30
  - NVRAM 42, 44
  - power supplies 18
  - principal, determining 46
  - priority 46
  - rerouting delay 43
  - setting date and time 38
  - SFP transceivers 18
  - tools supplied 20
  - unpacking and inspecting 24
  - verifying communication to HAFM appliance 36
- switch firmware
  - adding version 88
  - deleting a version 90
  - downloading 91
  - version 87
- switch parameters
  - domain RSCNs 44
  - insistent domain ID 43
  - NVRAM storage 42, 44
  - preferred domain ID 43
  - rerouting delay 43
  - suppress RSCNs on zone set activations 44
- symbols in text 10, 25, 28
- system
  - preventing electrostatic discharge to 101

## T

- Taiwan EPA battery recycling and disposal 100
- technical specifications, power requirements 106
- technical support, HP 11
- telephone numbers
  - FCC questions 96
- telnet, enabling 64
- text symbols 10, 25, 28
- toe straps, using 101
- tools
  - and test equipment 20
  - required for rack mounting 27
  - supplied by service personnel 21
  - supplied with switch 20
- tools, conductive type 101
- trap recipient IP addresses, default value 104

## U

- UDP port, default value 104
- UltraSPARC-II processor 67
- user rights, configuring, EWS 82

## V

- versions
  - firmware
    - deleting 90
    - determining 87
    - modifying description 90
  - HP-UX operating system 67
  - IBM AIX operating system 67
  - Internet Explorer 68
  - Netscape Navigator 68
  - Windows operating systems 21
- video card, remote workstation 67
- voltage compliance rating 100

## W

- warning
  - rack stability 11
- warnings
  - alkaline batteries 100
  - battery replacement 100
  - lasers, radiation 97

- web sites
  - HP storage [12](#)
  - HP Subscriber's choice [11](#)
- Windows operating systems, versions [21](#)
- work mat, static-dissipating [101](#)
- wrist straps
  - specifications [101](#)
  - using [101](#)
- WWN
  - binding [52](#)
  - principal switch [46](#)

## Z

- zone sets
  - default value [105](#)
  - description of [16](#)
- zones
  - members, default value [105](#)
  - number of, default value [105](#)
  - set state, default value [105](#)
  - states, default value [105](#)
- zoning, default values [105](#)

